

**YOU WANT THE BEST OUT OF THIS MACHINE. GIVE THIS
HANDBOOK TO THE MAN WHO HAS TO LOOK AFTER IT.**

BOOK 383/858

PRICE 10/-

MANUAL OF INSTRUCTIONS OPERATION

AND

MAINTENANCE PARTS LIST

FOR THE

TYPE JPM & JKM

2 & 3 Cylinder

Marine Propulsion

Diesel Engines

LISTER BLACKSTONE MARINE LIMITED


DURSLEY - GLOUCESTERSHIRE - ENGLAND

Telegraphic & Cable Address: POWER DURSLEY

Telephone: DURSLEY 2377

LUBRICATING OIL SYSTEM


LONGITUDINAL SECTION OF JP2MG/R ENGINE



- | | |
|---|--|
| <p>1. Crankcase Breather.</p> <p>2. Give grease cups half a turn daily for valve rocker lubrication. Refill as necessary (JPM only).</p> <p>3. Every week fill tops of push rods with oil, also put a drop of oil on exposed joints such as governor connections, etc.</p> <p>4. Fill with oil every week for valve lubrication.
a.</p> <p>5. Fuel Pump oil sump: Check oil level occasionally. Fill as necessary.</p> <p>6. Felt oil retainer.</p> | <p>7. Lubricating oil pressure pump.</p> <p>8. Lubricating oil scavenge pump.</p> <p>9. Lubricating oil delivery pipe to crankcase.</p> <p>10. Crankcase drain plug.</p> <p>11. Lubricating oil scavenge pump suction strainer.</p> <p>12. Filler Cap and Breather for Reduction Gear.</p> <p>13. Reduction Gear drain plug.</p> |
|---|--|


DRY SUMP LUBRICATING SYSTEM

- 1.—Air Vent.
- 2.—By-pass tube.
- 3.—Dipstick.
- 4.—Filling Cap.
- 5.—Discharge to Tank.
- 6.—Strainer Clip.
- 7.—Strainer.
- 8.—Pressure Pump suction.
- 9.—Drain Plug.



Lub. Oil Filter

Remove access doors from dry sump tank cover and release the spring rings which lock the filter gauzes in place. Lift out gauzes and thoroughly clean out tank at each oil change.



Referring to Fig. J8, the principal features of this system of Engine lubrication are as follows :

The oil supply is contained in a separate and external scavenge tank (H).

The Tank must be mounted with the bottom level with the Pressure Pump. It is provided with two large gauze strainers, dipstick (G) and drain plug.

A pressure regulating valve and by-pass are contained in a casting (E) which is connected into the circuit between the scavenge pump (D) and tank (H) and secondly between the pressure pump (C) and engine supply pipe (A).

The oil is taken from the oil tank (H) by the pressure pump (C) and passed by way of the pressure regulating valve to the engine through pipe (A).

After passing through the engine, the oil is drawn from the sump by the scavenge pump (D), and thence passed by way of the pipes (K & F) to the tank (H).

The oil tank can be mounted on the engine support brackets, or in a convenient position adjacent to the engine so that the bottom of the tank is just above the pump level.

Referring next to the sectional drawing of the pressure regulating valve, Fig. J6, it will be seen that oil from the pressure pump is supplied to the underside of the check valve through which it passes to the engine bearings. The function of this check valve is that of preventing the flow of oil, under gravity, from the tank into the engine whilst the latter is at rest.

In the event of the oil pressure exceeding the desired maximum, as determined by the upper spring, the check valve will lift against the upper spring seat, and the surplus oil be permitted to by-pass into the main chamber (M) and return to the tank.

Keep the oil connections free from leaks, and to ensure efficient operation remove the gauze strainers at frequent intervals and wash off impurities and sludge.

LUBRICATION

General

The type of lubricating oil suitable for use in a diesel engine is dependent on a number of factors of which the sulphur content of the fuel oil is perhaps the most important. In recent years the sulphur content of Class 'A' fuels has been increasing and fuels having a sulphur content of up to 1% and more are encountered. To minimise the ill effects of this high sulphur content only the best Heavy Duty Diesel Engine (Detergent) lubricants are recommended for use in Lister engines conforming to British Standard Specification 1905 or U.S.A. Specification MIL-L-2104A.

Viscosity—Grade of Oil recommended for different temperatures.

Below 32°F.
SAE 10

32°F.—85°F.
SAE 20

Above 85°F.
SAE 30

Branded Oils

In order to assist engine users a list of brands of oil normally obtainable in world markets which have proved satisfactory in our engines is given on page 14.

Mixing of Oils

If an engine has been run on straight mineral oil for more than 250 hours since completely overhauled (or since new) before it is changed to Heavy Duty (Detergent) Lubricants, the deposits formed by the straight oils may be dislodged by the latter and choke the oilways and filters. For this reason it is necessary to flush the engine thoroughly with Heavy Duty (Detergent) oil and change the oil after 50 hours and then resume normal changes every 450 hours. The filters must receive frequent attention during this initial period.


Sometimes Heavy Duty (Detergent) oils increase the oil consumption in which case a heavier grade may be used.

DO NOT MIX TWO DIFFERENT BRANDS OF OIL. THOROUGHLY DRAIN OFF THE ONE BEFORE ADDING THE OTHER.


LIST OF OILS COMPLYING WITH B.S. 1905/1952 AND U.S.A. SPECN. MIL-L-2104A

OIL COMPANY	SAE 10 or 10W BRAND	SAE 20 or 20W BRAND	SAE 30 BRAND
R. A. Lister & Co. Ltd.	Listroil L10		
Alexander Duckham & Co., Ltd.	Duckhams HD 10/MIL	Duckhams HD 20/MIL Tractor Diesel 20	Duckhams HD 30/MIL Tractor Diesel 30
Esso Petroleum Co., Ltd.	Essolube HD 10 Estor HD 10 Tro-Mar HD10	Essolube HD 20 Estor HD 20 Tro-Mar HD20	Essolube HD 30 Estor HD 30 Tro-Mar HD30
Valvoline Oil Co.	Super HPO 10	Super HPO 20	Super HPO 30
Germ Lubricants Ltd.	Germil 101	Germil 201	Germil 303
Power Petroleum Co., Ltd. (U.K.) BP Companies (Overseas)	Energol Diesel D-SAE 10W	Energol Diesel D-SAE 20W	Energol Diesel D-SAE 30
Regent Oil Co., Ltd. Texaco/Caltex	Caltex RPM Delo Special SAE 10W Ursa Oil HD-SAE 10W	Caltex RPM Delo Special SAE 20W Ursa Oil HD-SAE 20W	Caltex RPM Delo Special SAE 30 Ursa Oil HD-SAE 30
Shell Group of Companies	Shell Talona Oil 10W Shell Rotella Oil 10W	Shell Talona Oil 20 Shell Rotella Oil 20/20W	Shell Talona Oil 30 Shell Rotella Oil 30
Snowdon, Sons & Co.	Royal Snowdrift Apennine SAE 10	Royal Snowdrift Apennine SAE 20	Royal Snowdrift Apennine SAE 30
Mobil Oil Co., Ltd.	Delvac Oil 910 Mobiloil 10W (Overseas)	Delvac Oil 920 Mobiland Diesel 20	Delvac Oil 930 Mobiland Diesel 30
Vigzol Oil Co., Ltd.	New Ace 10	New Ace 20	New Ace 30
C. C. Wakefield & Co., Ltd.	Deusol CR 10 Agricastrol HD 10	Deusol CR 20 Agricastrol HD 20	Deusol CR 30 Agricastrol HD 30
Gulf Oil (Great Britain) Ltd.	Gulflube Motor Oil HD 10W Gulflube Motor Oil XHD 10W Gulf Dieselube HD 10W	Gulflube Motor Oil HD 20/20W Gulflube Motor Oil XHD 20/20W Gulf Dieselube HD 20/20W	Gulflube Motor Oil HD 30 Gulflube Motor Oil XHD 30 Gulf Dieselube HD 30 Brit-Gulf HD 30
Fina Petroleum Products, Ltd.	Solco HD 10 or 10W Solna HD 10 or 10W	Solco HD 20 or 20W Solna HD20 or 20W	
Edward Joy & Sons.	Diesel Filtrate 10	Diesel Filtrate 20	Diesel Filtrate 30

INSTALLATION IN A WOODEN VESSEL JPM ENGINE



J9



J10

A—Engine Bearers
B—Soleplate
C—Chocks

D—Holding Down Bolt
E—Nut welded to steel plate
F—Bulkhead stiffening

INSTALLATION

Careful planning is always advisable before installing a power unit, and Lister engines have been designed for maximum accessibility enabling a 100% overhaul in the craft. It therefore follows that advantage should be taken of these features, and the layout designed accordingly.

Bearers.

The engine bearers should always be of liberal thickness and as long as possible. They should form an integral part of the hull structure and be securely fastened throughout their length. At least two deep transverse floors should be provided in way of engine.

The primary objective when setting up bearers of a Marine Diesel Engine is to avoid a large concentration of stress that would endanger the fastenings and surrounding structural members. It is also essential that all holding down bolts should be a very neat fit. In wooden vessels the top of the bearers should be covered by a thin steel plate extending beyond the ends of the engine and secured in place by a number of counter sunk screws. The objective is not to provide strength but to supply a bearing surface for the engine bearers and holding down bolts. Long holding down bolts, preferably a large number of small diameter should be used to provide sufficient bearing surface to resist the thrust of the propeller and the torque reaction of the engine.

These bolts should be fitted at the lower ends with steel plates 2ins. x 3ins. (5 x 8 cm.), to which their nuts have been welded, to further spread the load over the bearers.

Rake.

The rake of these engines when installed, and craft on even keel, should not exceed 1 in 9 (i.e. $6\frac{1}{2}^\circ$).

Piping.

All pipes should have as short a run as possible in keeping with the space and facilities available. Where bends are necessary, however, they should be of a minimum radius not less than Diameter of Pipe x 5. Pipe friction reduces pump efficiency, but accessibility and ease of replacement are the major requirements.

Ventilation.

The efficient performance of any internal combustion engine depends on an adequate supply of cool fresh air. A rise of 10°F. (5°C.) in the air inlet temperature reduces the possible output of the engine by approximately 2%. It is therefore important that the engine room, or case, is well ventilated, admitting cool air below the engine and expelling hot air above.

Lubricating Oil Tank.

The Lubricating Oil Tank should be fitted in place as close to the engine as possible with the bottom on a level with the Crankshaft or not more than 12" above.

Fuel Oil Tank.

The fuel tank should be mounted in an easily accessible position with the bottom of the tank not less than 2ft. 6ins. nor more than 6ft. above the Crankshaft centre line.

Alignment of Engine and Tailshaft.

Temporarily the engine may be aligned to the tailshaft whilst the craft is out of the water, but should be checked again when water-borne. The couplings should remain unbroken whilst launching.

The overhang of the propeller, i.e., distance between the propeller and the outboard gland, should not exceed half the Tailshaft diameter.

In wooden craft a steel strip not less than 3/16" thick should be fitted along the top of the engine bearers, alignment can then be made with steel chocks as in steel ships. These chocks should be rectangular in shape 4" x 6" and thickness to suit, but not more than 1" thick. The chocks are fitted in way of the holding down bolts between the engine rails and bearer. With the engine in position and resting on these chocks, draw the tailshaft coupling up to face the gear box half coupling.

If alignment is correct the clearance between the coupling faces should show no variation and the weight of the engine should be equally divided between the six chocks, this state can be obtained by adjusting the thickness of the chocks with steel shims or machining the chocks as the case may be.

In wooden ships it is advisable to have the engine sitting a little high, say .005"—.010" to allow for pulling down when the holding down bolts are tightened up, due to compression of shims or bearer.

After hardening down, the alignment should be checked again before finally bolting up the coupling.


The coupling should be broken after its first run and checked and again periodically until the unit has finally settled down. New craft especially require careful attention during the first few hundred hours running, and all running temperatures should be carefully watched.

The foregoing should be STRICTLY adhered to.

STERN GEAR

Key

- A—Tail Housing
- B—Stern Tube
- C—For'd Bracket
- D—For'd Gland
- E—Water and Sand Seal
- F—Spring Ring
- G—Aft Bearings
- H—Locating Screw
- J—Packing
- K—Stauffer Grease Cup
- L—Annular Grease Space
- M—Grease Gun Height
Empty 12"
Full 19½"
- O—Grease Cup—¾ pt. Cap.
Optional (Part No. 501-1723)



IMPORTANT—PROPULSION ENGINES

The sterntube **MUST** be filled with a suitable grease, such as Vickers "Neox DT" immediately after installation. To ensure complete filling of the tube it is imperative that a grease gun be used for the initial filling. For service use regular attention to the grease cup provided should be sufficient to make up any loss incurred.

STANDARD TAILSHAFT SIZES AND STERN TUBE GREASE CAPACITIES

Tailshaft size	1½"—38.1 mm.	1⅝"—41.27 mm.	1¾"—44.45 mm.	2"—50.8 mm.	2¼"—57.15 mm.
Engine	JP2MG JK2MG	JP3MG JK3MG	JP2MGR JK2MGR	JP2MGR3 JK2MGR3 JP3MGR2 JK3MGR2	JP3MGR3 JK3MGR3
Grease Capacity (pints) litres	.96 .54	.46 .26	.34 .19	1.03 .59	.57 .33

STARTING

Before Starting Engine for the First Time or after Overhaul.

- (a) Remove Crankcase Door and pour two gallons of oil into the sump, then four gallons into the tank. Turn engine by hand until oil is seen emerging from Big-end Bearings and returning to scavenge tank.
- (b) Fill Grease Cups on Cylinder Heads and give several turns to lubricate Valve Rocker Arms. (JPM only).
- (c) Fill recesses in Cylinder Head with lubricating oil to just below level of hollow studs through which Push-Rods operate; this is for valve lubrication. Also fill cups in tops of Push-Rods.
- (d) Fill small sump in base of Fuel Pump to indicated mark with Engine Lubricating Oil.
- (e) Lubricate water circulating pump, and any Auxiliary Machinery driven from Engine.
- (f) When lubricating oil filter is fitted 2 extra gallons of lubricating oil must be added to fill the filter.

Starting by Hand.

It is advisable to always check Lubricating Oil level in Tank and Reduction Gear; check water system valves, and fuel valves, etc., before attempting to start the engine. Being satisfied that all is in order and that fuel system is primed proceed as follows :—

- (a) Raise decompressors to vertical position.
- (b) Screw in tightly the Compression Change Over Valves. (JPM only).
- (c) Release governor lever by lifting locking pins, and lift overload pawl. (This will return to normal as soon as engine starts).
- (d) Place Reverse Gear Lever in neutral position and move speed control lever to half speed.
- (e) Turn starting handle smartly and when rotating at good speed knock down decompressor levers one after the other. The engine should fire immediately the first cylinder is on full compression.
- (f) When engine starts, reduce speed to slow, and Check Lub. Oil pressure. Initially a very high pressure will be registered but on settling down and oil warmed through, the relief valve will regulate it to between 15 and 20 p.s.i.
- (g) Check cooling water flow, and give two turns to the grease cups on the water pump.
- (h) Before proceeding under way screw out the Change-Over Valves to low compression position, e.g., their full extent. For continued slow running over a long period at speeds below 850 r.p.m. the Change Over Valves should be screwed in. (JPM only).
- (i) The engine slow speed should be adjusted to tick over at 450-500 r.p.m. and the gears should not be engaged ahead or astern at a speed in excess of this. Serious damage can easily be caused to the gear unit by disregarding this warning, which should be brought to the attention of all drivers and coxswains.
- (j) When under way the water outlet temperature should be adjusted to 120°-130°F. (49°-54°C.) in salt water, but with closed circuit fresh water cooling it is permissible and beneficial to operate at temperatures up to 160°-180°F. (71°-82°C.).

Air Starting.

Check and set Engine as for hand starting.

Turn Flywheel to "START" position.

Screw in Compression Change-over Valves, except Air Start C.O.V. (JPM only).

Decompressor Levers must be left down.

Open Main Valve and Outlet Valve on receiver, and press Starting Lever. Engine should start in a few revolutions. Release Starting Lever.

Screw out Compression Change-over Valves (JPM only). Close Air Outlet Valve on Receiver and recharge Receiver.

To Charge Air Receiver.


With the Engine running, open the Inlet Valve on Air Receiver, release the Compressor clutch lever catch and engage clutch gently.

When the Pressure Gauge shows 450lbs./sq. in. disengage clutch, lock back lever and close Inlet Valve.

Inspect oil level in Compressor daily.

Oil Clutch Lever mechanism.

Inspect Air Pipe joints and test with soapy water for leaks.



AIR BOTTLE VALVE GROUP

A Main Stop Valve.

B Discharge Stop Valve.


D Charge Stop Valve.

S Safety Valve—set to 500 lb. p.s.i.

P Pressure Gauge.

Electric Starting.

Check and set Engine as for Hand Starting.
In this case Decompressor Levers must be left down.
Press starter button and release as soon as the engine fires.
Do not motor the Engine continuously for more than 10 secs.



STOPPING

To Stop.

- (a) Reduce engine speed to idling (450-500 r.p.m.)
- (b) Turn governor locking pin until its guide pins locate the deep slot.
- (c) Move the lever towards the fuel pump until the locating pin drops into its locating hole.
- (d) Shut sea cocks and check stern gland for leaks.
- (e) Do NOT shut off fuel supply to injection pump unless it is intended to clean both filters or carry out repairs. The engine should never be stopped by shutting off fuel supply, or lifting decompressor lever.

FAULTY STARTING OR RUNNING

Essentials for Easy Starting.

- (a) Engine must turn easily when decompressed; if not it may be due to :—
Unsuitable Lubricating Oil (too heavy).
Incorrect decompressor clearance.
- (b) Injector creak must be heard (or felt), if not it may be due to :—
No fuel in Tank.
Air Lock in System.
Injector nozzle valve stuck open.
Fuel Pump delivery valve scored.
- (c) Good compression, if not it may be due to :—
Worn Cylinder Liner.
Piston Rings carboned in grooves.
Leaking Inlet or Exhaust Valve.
Leaking Change-over Valve or not screwed in tightly (JPM only).
- (d) Fuel pump rack to be free (Stopping lever moved).
- (e) Overload Pawl on Fuel pump must be set for starting.

Knocking. This may be caused by :—

- (a) Valve, probably Exhaust, sticking in guide, and fouling Piston—clean stems and guides.
- (b) Slack bearing—fit new bearing.
- (c) Insufficient clearance between Piston and Cylinder Head—Check and adjust. (See page 33).
- (d) Injection too early—Check and adjust. (See page 39).
- (e) Flywheel loose on Shaft.

Carbon Deposit. Excessive deposit may be due to :—

- (a) Choked Exhaust system—dismantle and clean.
- (b) Long period of idling—running too cool.
- (c) Unsuitable Fuel Oil.
- (d) Unsuitable Lubricating Oil.
- (e) Injector not spraying correctly—clean nozzle.
- (f) Late injection of fuel—check timing.

Smoky Exhaust. The exhaust should be clear at Full Load. If it is not, steps should be taken to clear it. Black smoke is due to incomplete combustion of fuel caused by :—

- (a) Overload, causing an excessive quantity of fuel to be injected, check propeller.
- (b) Choked air intake.
- (c) Poor atomisation due to a choked injector nozzle.
- (d) Unsuitable fuel.

Blue smoke, when faint, is generally the result of light load or over-cooling.

Heavy blue smoke is caused by lubricating oil passing the Piston Rings, because of either Piston Rings carboned in grooves or a worn Cylinder Liner or Rings.

Engine Stops. This may be due to :—

- (a) Lack of Fuel. Air or Water in Fuel System. Fuel System choked.
- (b) Overload.
- (c) Overheating—shortage of water or lubricating oil.

Loss of Power. This may be due to :—

- (a) Loss of compression.
- (b) Incorrect Tappet clearance.
- (c) Choked Exhaust Pipe.
- (d) Fuel injection system. Injector out of order. Fuel Pump out of order, or timing slipped.

JPM & JKM

Fresh Water Cooling.

Fresh water cooling has been found, by experience, to prolong the engine life. Salt water causes corrosion and silting up of the water jackets, which is minimised by the use of clean fresh water.

Fresh water is circulated by an impeller pump through the water jackets by way of the crankcase ports, cylinder heads, water cooled exhaust manifold, and completes the circuit on returning to the heat exchanger. A drain cock is provided at the lowest point in the system for use especially in cold weather. A suitable 3 gallon make up fresh water header tank is provided to make good water losses from condensation and leakages.

It is important to note that the level of water in the fresh water header tank is maintained at all times and that the sea water suction strainer and sea cock are kept as clear as possible. The fitting of fresh water cooling does not allow the engine to be run in harbour when the tide is out, nor when the vessel is hauled out, unless an alternative cooling system is provided.

SEA WATER COOLING (GEAR TYPE PUMP)

The sea water pump, a high speed gear type, is driven through the camshaft gearwheel: it is fitted with moulded rubber impellers and rotates at approximately two-thirds of the engine crankshaft speed.

The suction elbow is so designed that when the engine is stopped sufficient water is retained in the pump casing that it should never be necessary to prime on starting. If the engine has been standing sufficiently long to allow evaporation to take place, the pump should be primed with half a pint of water through the plug hole in the discharge elbow.

Sea water is drawn from the engine sea cock and strainer to the pump and discharged through the water manifold into the silencer, thence to a port in the crankcase. After circulating around the liners it enters the cylinder heads through water ports and is induced to flow at high velocity, past and around the injector pockets. It flows thence around the valves and out of the head into the water outlet rail on the opposite side of the exhaust ports and then through a temperature control valve and over-board. The temperature control valve allows a proportion of the cooling water to be by-passed back to the pump suction and the main outlet restricted so that when starting up in very cold weather the engine may reach its working temperature as quickly as possible. This valve can be manually operated and is situated on the outlet water rail.


Relief valves are fitted on the discharge side of both the sea water and bilge pumps. The normal maximum operating pressure is 10 lbs. per sq.in and the relief valves are set to lift at 15 lbs. per sq.in. This will only occur in the event of a serious stoppage or defect in the piping system which should be rectified before further operation of the pump. In no circumstances should the pump be allowed to operate at a pressure in excess of that stated, or damage to the impellers will occur.

It therefore follows that the fittings on the sea water and bilge systems should be accessible and of an easily cleaned type. When engines are remotely controlled, or encased below decks, or where a complicated water system is employed, the relief valves should be resited on the end of a pipe and visible from the control position. It is important to fit a large capacity strainer in conjunction with the sea suction and to clear it at frequent intervals.

BILGE PUMP

The bilge pump and the impellers are protected from damage through lack of water by a bleed from the sea water pump discharge into the suction side of the bilge pump. This short length of pipe should be blown through from time to time. Although these pumps are so designed to pass small solids without damage, it is advisable to fit the bilge suction pipe with a strainer of the "elephants foot" type. Rubber pipes and connections should not be used in the bilge system as there is always a strong possibility of oil in the bilges and oil attacks and softens rubber of ordinary commercial quality. The bilge pump should never need priming as the sea water keeps it primed at all times.

The outer bearings of the pumps are lubricated by oil carried in a reservoir cast into the bearing housing and enclosed by the end cover. The oil is passed by felts to the spindle bearings and should be kept to the level shown on the cover at all times. The inner bearings are lubricated under pressure from the engine oil supply and returned through the crankcase door back to the engine.



Combined Sea Water and Bilge Pump

SEA WATER AND BILGE PUMP—GEAR TYPE

(a) To Remove Impellers :

Undo nuts (1) then remove four through bolts and end cover (2). Remove circlips (3) and pins (4). Slide the bearing housing (5) clear of the impeller shaft. Remove dividing plate (6) and pump body (7). Remove two rubber sealing rings (18) from shafts and slide off impellers. Further sealing rings on the shafts must then be removed. When a bilge and circulating pump is fitted it will be necessary to remove the second dividing plate (6), sealing rings and impellers.

(b) To Replace Impellers :

Reverse the above procedure. Fit new rubber sealing rings and paper joints between the dividing plates and housing, and between housing and end cover. The rubber rings must be fitted with soft soap. Pack the splines of the shafts with water pump grease before fitting sealing rings (18). Use only clean grease to stick the paper joints. After assembly fill the oil reservoir at the outer end of the bearing housing (5) with engine oil.

(c) To Remove Carbon Seals in Bearing Housing :

After removing the bearing housing as set out in paragraph (a), the following procedure should be adopted. Remove the circlips (10) then withdraw carbon seal driver (11), spring (12), thrust washer (13), rubber ring (14) and carbon seal (17) from the bearing block.

(d) To Fit New Oil Seals in Bearing Housing :

Proceed as paragraph (c). Remove bearing blocks (15) and oil seals (16). When pressing in new oil seals care must be taken not to damage the seal centre, and ensure they are correctly positioned. Before replacing the bearing block (15), to ensure that the centre of the oil seal will not be damaged, a knurled sleeve tool, Part Number 317-35, should be fitted into the bearing block housing and through the oil seal from the gear drive end. Then slide bearing block into position and withdraw knurled sleeve tool.

(e) To Fit New Carbon Seals in Bearing Housing :

Examine housing seal faces and where necessary lap these to ensure a flat surface for the carbon seal, fit each seal with new rubber rings (14) and circlips (10) to assembly, then reverse procedure in paragraph (c).

(f) To Remove and Re-fit Carbon Seals in Gear Housing :

Follow procedure as outlined in paragraph (a) and it will also be necessary to remove the remaining dividing plate (6), then follow the procedure in paragraphs (c) and (e) for removal of old parts and assembly of replacements, using the Circlip Assembly tool as follows :

1. Insert Tapered Circlip Loading Tool part No. 317-76 into Knurled Sleeve Tool part No. 317-75.
2. Place circlip on Tapered Circlip Loading Tool.
3. Push Circlip over the Tapered Loading Tool into position on the Knurled Sleeve Tool.
4. Slide Knurled Sleeve Tool over shaft serrations into required position and remove circlip with the aid of screw-driver or fingers.


(g) To Remove Impeller Shafts :

Procedure as outlined in paragraphs (a), (c) and (f). Remove bearing locating screws (19) and when removing the shafts it is essential that both should be removed as a unit, and by placing a block of wood across the ends of these shafts and gently tapping out so ensuring that no damage is caused to either bearings (20) or the ends of the shafts (23) and (24).

(h) To Fit Replacement Shafts :

Fit bearings (20) keeping oil groove at gear teeth end, slide on thrust washer (21) and secure with circlips (22). After assembly of these parts ensure that there is free radial movement of the bearing on the shaft, then fit bearing bush (25) in the end of the recess of the bottom shaft (24). Before assembly of the shafts into the gear housing examine oil seals (16) for wear and if necessary renew. Assemble the shafts in position, putting the timing mark "O" on the tooth of the pinion of the top shaft (23) in between the "O" marks on the teeth of the pinion of the bottom shaft (24). Tap the gear shaft assemblies into the gear housing together, keeping the locating holes in the bearings in line with the locating screw holes in the housing (27), taking care not to damage the oil seals when fitting the shafts. This should not occur if the pump assembly tools as shown are used. To secure the shafts in position in the gear housing screw in position the locating screws (19) and secure. Fit the reduction gear (26) to top shaft (23), making sure the driving dowels are in position. To re-assemble pump, reverse the procedure of paragraphs (f), (b) and (a).

TOOLS FOR GEAR PUMP



Tools for Gear Type Water Pump

	Part No.		Part No.
a Knurled Sleeve Tool	317-35	12 Gland Spring	291-2152/4
b Guide Bar Tool	317-37	14 Rubber Ring	291-2527/1
c Tapered Sleeve Tool	317-36	15 Bearing Block	291-2540/1
d Snap Ring Loading Tool	317-76	16 Oil Seal	291-2153
e Bearing Block Bush Drift Tool	317-48	17 Carbon Seal	291-2150/1
5 Bearing Housing	291-2514/1	23 Pump Shaft	291-2510/4
10 Snap Ring	291-2975	27 Gear Housing	291-2501/1

MAINTENANCE ROUTINE

When Engine is in continuous use:-

Daily

Check supply of fuel oil.
Check leaks of oil, water, fuel.
Check level and state of lubricating oil.
Check level of oil in air compressor.

Turn Grease Cups. JPM only.
Check water circulation.
Check water temperature.
Check exhaust smoke.
Check lubricating oil pressure.

100 hours.

Clean Air Filters.
Oil Starter and Generator bearings.
Drain Moisture Trap (if fitted).

Check condition of Starter Battery (if Electric Starting).
Check tightness of all nuts.

450 hours.

Change Engine oil.
Clean Lubricating Oil Filter.
Check Water Pump and Air Compressor.

Remove Injectors and check fuel spray.
Check Reverse Gear Adjustment.
Lubricate auxiliary machinery.

1,000—1,500 hours.

Decarbonise.
Clean Fuel Filter.
Check Piston clearance if gasket is changed.
Grind in Valves.

Clean Compression ratio valve screw (JPM only)
Adjust Valve clearances.
Clean out Heat Exchanger (if fitted).

3,000 hours.

Clean out Inlet Manifold and Exhaust Pipes.
Check Water Jacket for scale.
Clean vent holes in Cylinder Block.
Check free working of Governor linkage.
Drain sediment from main Fuel Tank.

Renew Fuel Filter Elements.
Check Injector nozzles for obstructions or wear in orifice.
Check Big Ends and Main Bearings.

A reasonable amount of time spent in checking over the details as described in the foregoing, is the user's best insurance against loss of valuable time and costly repairs.

MAINTENANCE

Changing Lubricating Oil. Every 450 hours.

Drain oil from Engine and tank when warm, through Drain Plug underneath the Engine close to the Lubricating Oil Pump. Drain and clean out tank.

Remove Crankcase Doors and wipe down inside as clean as possible.

If paraffin is used to swill out sludge, Crankcase must be wiped dry before recharging with fresh oil.

Remove, clean and replace Oil Filter in sump and Strainers in tank.

Lubricating Oil Filter.

To remove Filter (JP2M & JK2M Engine) remove crankcase door, remove nut in the top centre of the Scavenge Oil Pump casing; this will allow the filter to be extracted from the Crankcase. Do not lose two small fibre washers on end of the filter which seal inlet connection to the pump.

To remove Filter (JP3 & JK3M Engine) remove crankcase door, unscrew union nut on pipe securing it to the adaptor; filter and pipe may be extracted from Crankcase.

Wash both filters carefully in paraffin and examine fine gauze for perforations; renew if holed. Dry thoroughly and replace.

Fuel Injector.

Examine the nozzle periodically and clean if necessary. The use of absolutely clean fuel is essential for good injection and complete combustion.

A faulty nozzle may result in one or more of the following :—

- | | |
|-------------------------------|---------------------------------|
| (a) Smoky Exhaust (Black). | (d) Engine overheating. |
| (b) Loss of Power. | (e) Increased fuel consumption. |
| (c) Knocking in the Cylinder. | |

To test a nozzle, remove from Cylinder Head and re-connect to Fuel Injection pipe with the nozzle exposed. Turn the engine until the nozzle sprays into the air away from the operator (the spray will easily penetrate the skin of the hands), when it will be seen if the spray is "streaky" or "dribbling"; a perfect spray is in the form of a fine mist.

The nozzle must only be cleaned with the necessary special tools and by a qualified Service engineer.


To remove the nozzle and valve, secure the injector body in a vice and unscrew nozzle cap nut. When replacing or renewing the nozzle and valve, it is essential to locate the two dowels and valve spindle correctly before replacing the cap nut.

If in any doubt, replace a complete Injector; body and nozzle.

The defective or dirty unit must be returned to a Service Depot for attention.

Important.

Apart from the attention given to the Fuel Pump Coupling, Delivery valve and seat and the changing of defective Injector nozzles and valves, ALL other work on the Fuel Injection System must be carried out by suitably equipped Service Depots.



Fuel Oil Filter

- | | |
|------------------------------|------------------------------|
| 1. Vent Screws. | 5. Fuel OUTLET to Fuel Pump. |
| 2. Filter Change-over Lever. | 6. Drain Plug. |
| 3. Filter in use—indicator. | 7. Water Heating Inlet. |
| 4. Fuel INLET to Filter. | 8. Water Heating Outlet. |

Cleaning Fuel Filter (1,000 - 1,500 hours).

- (a) Shut off fuel from Tank.
- (b) Disconnect fuel pipe from Filter Cover and plug the hole in the cover with a wooden plug or cork.
- (c) Undo nuts and remove cover together with Filter Element.
- (d) Remove cage from the Filter Element but do not remove Filter Element from cover.
- (e) Wash Filter Element in clean paraffin or fuel oil, taking care that no dirt or dirty liquid enters Filter Element through hole in cover.
- (f) Empty and clean out Filter Body.
- (g) Assemble by reversing order of dismantling.
- (h) Open Fuel from Tank and prime Filter by slackening Vent Screw until all air has been driven out and only fuel flows.
- (i) Should element require replacing it is important that the cover is thoroughly cleaned before removing the old element. This will prevent fine particles of foreign matter entering the threaded hole from the outlet connection.

Vacuum Breather.

The purpose of the Vacuum Breather on the Crankcase is to maintain a partial vacuum in the Crankcase so that the lubricating oil will not work out through the joints.

If the thin metal disc should become stuck with paint or grime, remove and scrape clean on a flat surface, care being taken not to kink or distort it. Do not mislay the small distance piece which supports the cover.

The Breather is fitted to the JP3M Engines only.

The JP2M Engines have the Body of the Breather without the metal disc.

Compression Ratio Change-over Valve (JPM only).

This is a device to give a high compression for starting, and a lower compression for normal running.

The valve screwed "IN" gives high compression and "OUT" gives low compression.

Do not run under heavy load with high compression.

For long runs at half load or less, use high compression.

Always see that the Valve is either **Fully in or Fully out.**

Keep the screw thread clean and bright.

To Remove Compression Change-over Valve (JPM only).

(a) Remove fuel pipes from injector and unscrew nut for releasing auxiliary chamber. This will withdraw the outer combustion chamber. Take note of the thin copper washer.

(b) The Main or Inner Combustion Chamber Plug may need to be loosened by compression.

Drive a hard wooden plug into the $\frac{1}{4}$ " dia. hole in the centre to prevent air leakage and then replace the outer portions just removed, with the handwheel in the "out" position, and with the outer combustion chamber nut screwed into the head 3 or 4 turns, which will be sufficient to prevent the inner combustion chamber from being ejected too violently when subjected to the force of compression.

Stubborn cases will have to be treated by drilling and tapping the inner plug with a fine $\frac{1}{8}$ " thread and drawing out with a screw.

(c) Unscrew small nuts in centre of hand wheel to extract Valve.

(d) Remove valve, taking care of spring, spring washer and woodruff key.

To Remove Cylinder Head.

(a) Drain water.

(If Compression Change-over Valve is to be removed, loosen at this stage). (JPM only).

(b) Remove Cylinder Head Cover.

(c) Remove Injector.

(d) Detach Inlet Manifold. Exhaust Manifold. Water Outlet Manifold.


(e) Remove Valve Rockers by loosening small screws and sliding out Valve Rocker shaft.

(f) Remove Valve End Caps and lift out Push Rods.

(g) Unscrew nuts on Cylinder Head Studs and nuts on Hollow Studs.

(h) Lift off the Cylinder Head. In obstinate cases, replace the Injector (but not the Fuel pipes), Valve Rockers and 2 Cylinder Head holding down nuts; slacken each of these holding down nuts about 2 turns and replace Cylinder Head Cover.

Next proceed as for starting, with the Decompressor Levers in the "UP" position, turn the starting handle quickly to get a good speed and then smartly knock down the appropriate Decompressor Lever, when the compression in the Cylinder should loosen the joint between Cylinder Head and Crankcase.



To Remove Valve Guides.

The Inlet Valve Guide may be driven out.

The Exhaust valve guide must be screwed out (turn anti-clockwise).

To Replace Cylinder Head.

- (a) Refit Valve Guides, Inlet and Exhaust Valves; (Compression Change-over Valve JPM).
- (b) See that Cylinder head gasket is undamaged and in place, i.e., located by dowel pin.
- (c) Replace Cylinder Head on studs and tighten nuts finger tight.

Note.—Each Cylinder Head Gasket must be replaced on its own cylinder. If these have been changed, then the Head clearance must be checked as below.

- (d) Fit exhaust and inlet Manifolds to ensure correct alignment. Failure to carry out this step will probably lead to cracked or broken Manifolds.
- (e) Nuts to be tightened so that the Cylinder Head is pulled down flat. Tighten each nut a little at a time and go over all nuts 3 or 4 times.
- (f) Replace Valve End Caps, Push Rods and Valve Rocker Gear and adjust valve clearances as under "Valve Adjustment."


To Check Cylinder Head Clearance.

Place two small pieces of lead on top of Piston, above the line of the Gudgeon Pin and not beneath the valves or transfer port. Tighten down Cylinder Head and turn Piston slowly past T.D.C. Remove Cylinder Head and measure thickness of lead; if this does not fall between .045in. and .050in., the clearance may be adjusted by the addition of a copper shim .005in. thick, placed next to Cylinder Head.

If the clearance is much too large it may be due to worn bearings or a bent Connecting Rod.

To Remove Piston

- (a) Remove Cylinder Head.
- (b) Remove Crankcase Doors.
- (c) Disconnect the Big End of the Connecting Rod. The best position for reaching the nuts will be found when the Piston is $\frac{1}{4}$ " below T.D.C. Note the manner in which the Big End is marked.
- (d) Bring the Crank into the vertical position, then raise the Connecting Rod, turn it through 90°, and stand it on the crank web
- (e) The Cylinder Liner is cut away on either side. This allows the Connecting Rod to be pushed up until the Gudgeon Pin rises clear of the Cylinder. A wood block is placed for the Big End to stand on.
- (f) Remove the spring circlip retaining the Gudgeon Pin on the side opposite the tubular studs.
- (g) Warm the Piston (a cloth dipped in hot water, lightly wrung out and placed on top of the Piston once or twice), drive out the Gudgeon Pin and remove the Piston, the Connecting Rod can then be removed through small crankcase door.



Withdrawing Piston

To Remove Piston Rings.

First work them loose, then stand the Piston on a flat surface and insert thin strips of metal between the top Ring and the Piston at four different places. Ease the Ring off over the strips of metal and repeat the process for the other rings. Piston Rings are springy but will break if roughly handled.

To Replace Piston Rings.

- (a) Piston, grooves and oil holes must be thoroughly clean. Piston Rings, if new, must be wiped clean of preservative grease; used ones must have any carbon deposits removed.
- (b) To ensure that the Rings (except the top one which is tapered) will fit properly when assembled on the Piston, roll each one round in its own groove. Where a Ring is slack, and a new one is no improvement, it will be necessary to consider changing the Piston.
- (c) Place the Ring in the lower part of the Liner and measure the gap between the two ends with a feeler gauge. The correct gap is not less than .012".
- (d) The Rings must be replaced in their same grooves and the same way up. Wipe all parts clean and dry and assemble the Rings into their grooves by sliding them over strips of metal as in removal.


To Replace Piston.

- (a) Oil the Cylinder bore copiously and place Connecting Rod in position (Standing on wooden block).
- (b) Warm Piston, lower into bore and insert Gudgeon Pin. Tap well home and fit clips. Turn Connecting Rod 90°—see that Big End bearing marks are on correct side.
- (c) Oil the Piston Rings and stagger the gaps. Place the Piston Ring clamp in position and compress the Rings. The clamp should close quite easily. If any force is required it is better to take it off and try again.
- (d) Remove wood block from the Crank Web, oil and turn crank to T.D.C. and with a hammer shaft press the Piston down into the Cylinder. Maintain this pressure on the Piston while the crank is turned for assembly of the Big End bearing.

To Replace Cylinder Liner.

When fitting a new Liner ensure bore and shouldered seating "A" and rounded surface "B" are clean and smooth. If the shouldered seating in the Crankcase has a sharp edge this should be scraped or faced off to form a chamfer "C." Insert new Liner (without rubber rings) and grind in seatings "A" with grinding compound as for Valves. The top face should project from .006" to .008" above the face of the Crankcase. Snear two new rubber rings "R" with soft soap and place, without twisting, in top and bottom grooves on the Liner. Liner should slide freely into place, if it does not, remove and examine rubber rings. Renew if damaged.

Press Liner right home ensuring that line on flange of liner is in line with longitudinal centre line of the Crankcase. When a new Liner has been fitted, the Cylinder Head clearance should be adjusted.



Cylinder Liner

IMPORTANT.

The middle groove on Liner comes opposite the small "Tell Tale" hole in Crankcase, just above the inspection door. Should water pass the top rubber ring it would drain out through this hole which serves as a warning of the failure of the top ring.

Connecting Rod Big Ends.

These are fitted with steel backed white metal bearings, which should fit freely on the crankpin. The clearance should not exceed .004". So that the two halves of the bearings shall register firmly one against the other, the Big End Cap is made to draw up to within .002" of the top half. This "nip" should be measured with a feeler gauge after assembly with the Big End nuts just drawn up but not tightened. It may be necessary to scrape a new bearing to obtain a correct fit.

If the Big End has been dismantled because of failure of the white metal, the oil passage in the Crankshaft must also be examined for obstruction and fragments of white metal. After cleaning out it is advisable to crank the Engine over by hand to see that oil reaches the bearing, and to flush out the oil passage.

Main Bearings.

These are of the bush type and need no attention as long as they are properly lubricated. Undersize main bearings are available .010", .020", and .040" undersize.

Note.—When a Crankshaft has been reground, an undersize Pinion will be required as well as the undersize bearings.

Valve Adjustment.

Valves should be set to .008" clearance when **COLD**.

To do this, remove Cylinder Head Cover, slacken off the locknut on top of the Valve Rocker, turn the adjusting screw until the correct clearance is obtained between the Valve and Rocker and then tighten the locknut. During this operation the Valve Tappet must be in its lowest position, and the rocker pressed firmly down on the tappet rod.

Inlet Valve opens 10° early and closes 50° late. Exhaust Valve opens 45° early and closes 15° late.

To Remove Valves.


- (a) Remove Cylinder Head. (See page 31).
- (b) Lay head upright on bench.
- (c) Depress Valve Spring Carrier.
- (d) Remove Valve Stem Cone (in two halves).
- (e) Remove Valve Spring Carrier and Valve Springs.
- (f) Turn Cylinder Head over, and remove Valves.

To Replace Valves.

Replace components in the reverse order and check the Valve Head clearance.

Position of Valve Heads.

Exhaust Valve head must be not less than .012" under face of Cylinder Head. Inlet Valve must be not less than .004". The maximum for both Inlet and Exhaust Valves is .100".



JKM Exhaust Valve Assembly

Decarbonising.

Decarbonise the Engine after 1000 - 1500 hours running. This is an average figure and will depend on running conditions.

- (a) Remove and dismantle Cylinder Head.
- (b) Remove Piston and Rings.

All Parts must be scraped clean of deposits of carbon and washed in Paraffin before re-assembly.

Special care must taken with regard to:—

- (a) Recess in bore of Exhaust Valve Guide
- (b) Valve Ports.
- (c) Piston Ring Grooves.

Regrind Valve seats if not in perfect condition.

This applies also to the Compression Change-over Valve (JPM only).

Clean out exhaust manifold and silencer. Every part must be scrupulously clean before being placed in position.

To Adjust Decompressor.

The Overhead type of Decompressor is spring loaded and will jump if for any reason the Piston should touch the Exhaust Valve Head. If this should happen, screw down the nut on top of the Cylinder Cover until the Decompressor can be operated without interference from the Piston.


Flywheel.

The Flywheel need not be disturbed except for the removal of main bearings or crankshaft. Should this be necessary, the flywheel nut must **Not** be unscrewed more than 2 turns before the flywheel is loosened.


Crankcase End Cover.

Before removing the end cover, the exposed crankshaft must be made smooth and clean and the keyway turned to the bottom. This will preserve the Main Bearing which comes away with it.

To Replace End Cover.

The timing of the Fuel Pump Gear Drive is set when replacing the End Cover. Turn the Fuel Pump Coupling so that the line R on the coupling coincides with the vertical line on the pump body. Set No. 1 Piston to injection mark  on Flywheel on compression stroke (No. 2 Piston for JP2M or JK2M) and push cover home. A slight misalignment of the R mark may be disregarded as this will be corrected at the final adjustment of the vernier coupling. No. 1 Cylinder is at Fuel Pump End of Engine.

Firing Order for 3 cylinder Engine : 1, 3, 2.



Fuel Pump Coupling

To Remove Crankshaft.

- (a) Drain oil and water from Engine.
- (b) Remove Cylinder Heads.
- (c) Draw Pistons and Connecting Rods.
- (d) Remove Flywheel and Crankcase End Cover.
- (e) Remove Pressure Gear Cover and Gear Unit.
- (f) Remove Crankshaft Spur Gear and Outer Main Bearing Gear End.


- (g) Release any intermediate bearings. In 3 Cylinder Engines these are secured by long setscrews through the side of the Crankcase.
- (h) The Crankshaft, together with Pinion, inner Main Bearing gear end and intermediate Main Bearings, is now free; lift the whole unit out through the Crankcase.

Before replacing Crankshaft, give all oil passages a thorough cleaning.

Take this opportunity to give the inside of the Crankcase a good wash down with paraffin.

Make certain that all bearings are entered the right way up for the oil holes, particularly the centre bearings for 3 cylinder engines.

The correct Crankshaft end clearance is .005" to .010". This clearance must be available on the locating main bearing before re-assembly in the crankcase. If it has been reduced after fitting the end cover, an additional end cover gasket must be fitted.




Camshaft Timing

To Time Camshaft.

- (a) Place Gear Wheel in position, engaging the tooth marked "O," with the corresponding gap on the Crankshaft Pinion. Allow the Gear Wheel to roll over and rest on the Crankcase.
- (b) Insert Camshaft, with key in position, and work along through the bearings, at the same time, replacing the Tappets.
- (c) Roll Gear Wheel back until it engages with the Camshaft end. Drive Gear Wheel home and fit securing nut and locking washer.

TIMING DIAGRAM



TIMING DIAGRAM

A

Fuel Injection : 26° BTDC JPM & JKM over 1200 RPM.
24° BTDC JPM & JKM up to 1200 RPM.



Exhaust Valve Opens

Inlet Valve Opens

CYLINDER FIRING ORDER :

1, 3, 2—3 cylinder

FUEL EQUIPMENT

To Prime Fuel System.

Prime the fuel system by removing ALL air :—


- (a) With fuel tank filled, prime Filter by unscrewing Vent Screw on top of Filter until all air is released and the oil flows freely. Re-tighten screw.
- (b) With Governor Lever Handle in "STOP" position, and locking pin in slot, disconnect fuel injection pipe from delivery valve holder on Fuel Pump, by unscrewing the union
- (c) Remove delivery valve holder and spring, and with the fingers slightly raise delivery valve from its seating. As soon as this is done fuel should appear. Hold delivery valve off its seat until all air bubbles are out of the system and a solid column of fuel oil appears. Replace delivery valve holder and spring and tighten down holder firmly but not too vigorously.
- (d) Connect fuel injection pipe again to Fuel Pump and loosen at Injector Union. Repeat for all cylinders.
- (e) Place Governor Lever Handle in "START" position by withdrawing locking pin. Engage starting handle and turn Engine by hand until oil flows freely from Injector unions.
- (f) Tighten unions and continue turning Engine until Injectors "creak" or a distinct "buzz" is felt in the Injector pipes.

Timing Fuel Injection by Spill Cut off.

This is to correct the rough timing given by the "R" mark.


- (a) Set Governor Lever to Starting Position.
- (b) **For JPM and JKM engines up to 1200 RPM.** Set the crankshaft in firing position for No. 1 cylinder (No. 2 cylinder on two cylinder engine) this is 24° before TDC, or 4.85" measured on the rim of 23" flywheel.
- (bi) **For JPM and JKM engines over 1200 RPM.** Set the crankshaft in firing position for No. 1 cylinder (No. 2 cylinder on two cylinder engine), this is 26° before TDC, or 5.2" measured on the rim of 23" dia. flywheel.
- (c) Disconnect the fuel injection pipe from No. 1 Cylinder of Fuel Pump, No. 2 on JP2M & JK2M. **Always** the Pump nearest the coupling.
- (d) Remove delivery valve holder, delivery valve and spring.

Note.—Fuel may flow from the pump. If so, rotate Crankshaft forward till it ceases.


- (e) Replace delivery valve holder (without valve and spring) and tighten lightly.
- (f) Now turn the Engine backwards slowly until the fuel recommences to flow, then turn in the direction of rotation, until the fuel flow ceases. Blow fuel off the top of the delivery valve holder to make sure that the flow has definitely stopped. At this position the mark on the flywheel, which indicates injection  should be immediately opposite the line on the end of the engine crankcase. If not, adjust the vernier coupling on the pump drive.
- (g) Replace delivery valve and spring after washing them in clean fuel oil.
- (h) Reconnect fuel injector pipe.
- (i) The other cylinders could be checked in similar manner if in any doubt.

C.A.V. Fuel Pump

The pump element is comprised of the plunger and barrel as shown below. When the plunger is at B.D.C. as at (a), oil enters through the barrel ports by gravity from the daily service tank.



In a properly primed system the barrel and the pipes leading from the pumps to the injectors are full of fuel. As the pump plunger rises a certain amount of fuel is pushed back through the barrel ports, until the plunger reaches the position (b) where the top land of the plunger has closed both ports. The fuel above the plunger is then trapped, and its only outlet is via the delivery valve which is mounted on top of the pump barrel. The pressure exerted by the rising plunger upon the oil causes this to lift the valve and to enter the pipe which connects the pump to the injector. As this is itself already full of oil, the extra oil which is being pumped in at the pump end causes a rise in pressure throughout the line and lifts the nozzle needle (or injector valve). This permits oil to be sprayed into the engine combustion chamber. Thus at this moment we have oil being pumped into the line at the pump end, and an equal quantity being pushed out at the nozzle end. This continues until the plunger reaches the position shown at (c). Here the lower edge of the control helix has uncovered the barrel port, thus allowing fuel to be by-passed back to the suction chamber (which is under a very much lower pressure than the fuel oil above the plunger) by way of the vertical slot. This causes the delivery valve to shut under the action of its spring, and with the consequent collapse of pressure in the pipe line, the nozzle valve also shuts. The plunger stroke is always constant, but that part of it which is actually pumping is variable. By means of the helical edge which runs around the plunger, which itself can be rotated within the barrel, it is possible to make this point of cut-off occur earlier, or later in the stroke—compare positions shown at (c), (d) and (e) which show full load, half load and idling, respectively. To stop the engine the plunger is turned so that the vertical slot coincides with the barrel port (see f) during the whole of the plunger stroke; thus no fuel is delivered. The position of the plunger stroke at which the helical edge will uncover the port is adjustable by rotating the plunger axially by means of a toothed quadrant which is clamped to the sleeve having slots engaging the lugs of the plunger at its lower end. The toothed quadrant engages with a collar provided on the control rod which similarly actuates all the pump elements in the unit, and is externally connected to the governor.



Delivery Valve Unit


Anti-Dribble Device.

When the helical edge of the pump plunger uncovers the port on the pump barrel near the end of the delivery stroke, the pressure of fuel is immediately reduced so that the delivery valve at once drops on its seating, thus cutting off communication between the pump and the nozzle until the next delivery stroke takes place. In coming to its seat to act as a non-return valve, the delivery valve is, however, made to perform the other highly-important function of pressure unloading. The double function is obtained by means of the novel but entirely simple construction of the delivery valve unit, and reference to the Figure will show that it is an ordinary mitre-faced valve with a guide which has a circular groove cut in it, dividing the guide into two parts. The lower part has four longitudinal grooves communicating with the circular groove. The upper part of the guide forms a small piston, which is an accurately ground plunger fit for the valve seating which is also ground. When the pump is on its delivery stroke, the pressure of the fuel rises and the delivery valve is pushed up until the fuel can escape through the longitudinal grooves over the valve face to the nozzles. Immediately the pump plunger releases the pressure in the barrel, the delivery valve (under the influence of its spring and the great difference in pressures between the pump barrel and the delivery pipe) resumes its seat, causing the small piston part of the guide to sweep down the valve seating with a plunger action, thus increasing the space in the delivery pipe (by an amount equal to the volume of the small piston part of the valve guide) before the valve actually seats itself.

The effect of this increase in volume in the delivery pipe system is, of course, that of suddenly reducing the pressure of the fuel therein so that the nozzle valve in the nozzle can "snap" to its seat, thus terminating instantaneously the spray of fuel in the cylinder, entirely without "dribble."

Control of Output.

The word "Stop" and an arrow engraved on the top at one end of the control rod indicate which way the control rod should be moved to stop the engine.




Sectional View of Fuel Pump.

Injector.

The complete injector consists of two parts, (a) the nozzle holder and (b) the nozzle.


The nozzle holder contains the pressure controlling spring, and the pressure can be adjusted by the screw and locknut to 2200-2400 p.s.i. (154-168kgs./sq. cm.).



C.A.V. Fuel Injector

The nozzle valve and nozzle body are shown separately in the figure below. The nozzle valve takes the form of a plunger accurately lapped into the nozzle body to the closest possible fit, within which it will work freely. On one end of the nozzle valve, a stalk is provided, whilst at the other end it is reduced in diameter to produce a stem upon which a valve face is formed.

Fuel is fed to the mouth of the nozzle through small tunnels bored vertically in the nozzle body which terminate in an annular reservoir or "gallery" just above the valve seat. The nozzle valve is raised from its seat in the nozzle body by the pressure of fuel being fed from the injection pump, and the accumulated fuel in the "gallery" is forced by the upward movement of the plunger in the pump, through the hole or holes in the nozzle, thus forming a "spray" in the engine combustion chamber.




C.A.V. Nozzle Valve and Body

FAULT LOCATION IN FUEL PUMP.

FAULT	PROBABLE CAUSE	SUGGESTED REMEDY
Pump does not deliver fuel.	<ol style="list-style-type: none"> 1. Fuel tank empty. 2. Fuel inlet pipe choked or filter element dirty. 3. Air lock in pipe line. 4. Delivery valve remains suspended. 	<p>Partly unscrew vent plug until fuel flows freely, without any air bubbles.</p> <p>Remove and examine valve face and guide, as well as seating face. If either are damaged, the pair should be replaced.</p>
The pump does not deliver fuel uniformly.	<ol style="list-style-type: none"> 5. Supply of inlet fuel to pumps insufficient. <ol style="list-style-type: none"> (a) Inlet pipe choked or filter element dirty. (b) The "head" between the tank and the pump is too small. 6. Air lock in pump shown by air bubbles issuing when the delivery valve holder has been unscrewed. 7. Delivery valve spring broken. 8. Delivery valve damaged either on face or guide. 	<p>Proceed as at 3.</p> <p>Increase the head.</p> <p>Proceed as at 3.</p> <p>Replace.</p> <p>Fit new pair (i.e., new valve and seating complete).</p>
Quantity of fuel delivered per stroke insufficient.	<ol style="list-style-type: none"> 9. Delivery valve leaky. 10. Leaky joints in the pressure 	<p>Fit new pair (i.e., valve and seating).</p>

12v. ELECTRIC STARTING EQUIPMENT (JPM)

DYNAMO AND STARTER MOTOR MOUNTING



J32

DYNAMO AND STARTER

Dynamo

With the compensated voltage control system there is automatic adjustment of the charging rate in relation to the condition of the battery. Once a dynamo has exceeded the cutting-in speed, the output voltage is kept slightly in excess of the back pressure of the battery irrespective of any variation of speed. In addition the excess voltage of the dynamo is made greater as the battery becomes discharged and less as the battery becomes more fully charged. The current voltage control system charges a partially charged battery at a constant current until a certain battery voltage is reached when the charging changes to constant voltage control. This latter then allows the charging current to drop as the fully charged state in the battery is approached, until it reaches the normal trickle charge value.

Testing.


First remove all cables from the terminals. Then make a short wire connection between the terminal marked 'F' and the Positive main terminal, which is connected internally to the brush gear. Connect a moving coil type voltmeter, having a suitable range, across the two large main terminals, and run the engine up to such a speed as will give a reading of 13 volts on the voltmeter. Do not, however, exceed engine revs. of 850 r.p.m.

If the voltmeter remains at zero check the dynamo brush gear, and internal connections. A very low reading throughout the rise in engine speed indicates a possible faulty field winding, or possibly that the armature winding is faulty.

Starter.

The Starter is of the "Axial" type, so termed because the armature with its shaft, is capable of an axial movement in its bearings, and when extended it engages the pinion with the teeth on the flywheel rim. It is held in a disengaged position by means of a coil spring fitted inside the shaft at the commutator end, the armature being thus kept out of complete register with the pole shoes.

When the Starter Button is pressed a small current passes through the auxiliary windings, causing the armature to rotate slowly. Simultaneously, the magnetic field set up pulls the armature forward which brings the pinion gently into mesh with the engine flywheel teeth. This movement of the armature also causes the contacts of the solenoid switch to be released, thereby completing the main circuit. The full battery current then flows through the armature and the series field windings, and the motor exerts its full torque on the engine. When the engine itself gets under way, the motor current is greatly reduced, the magnetic field is decreased in power, the tension of the spring overcomes the force exerted by this residual magnetic field and the pinion automatically disengages.



A—Glass Paper.

Bedding in Brushes

Testing.

If the starter fails with a fully charged battery connect a voltmeter across the main terminals. If the reading is zero when the Starter Button is pressed again the fault lies between the Button and the Starter, or between the Battery and the Starter.

Bad electrical contacts in the switch, on the Starter Terminals, or on the Battery will give rise to intermittent operation of the Starter when the Button is pressed.

Maintenance.

Inspect the Brushes every six months, and see that they are free in their guides and that their flex leads are perfectly clear for movement. Positive and negative brushes and holders must be insulated from one another. These can be tested by means of a lamp but it is not necessary to remove the brushes while testing, provided that they are lifted from the commutator before commencing the test.

If, for any reason, they are removed, take care to replace them in exactly the same position in the brush holder, so that the bedding curvature will accurately conform to the diameter of the commutator. If they are not well bedded to this curvature, wrap a piece of fine glass paper around the commutator and, with the brushes in position, rotate the armature by hand in the normal direction of rotation until the correct brush shape is obtained.

See that they have not worn so that the trigger or spring is no longer providing effective pressure.

Test the brush spring pressure by means of a spring balance hooked under the spring trigger or spring tips.

Dynamo Springs: 12-19 ozs.
Starter Motor Springs: 32-40 ozs. The pressure can be varied by twisting the spring into different slots on the trigger.

Test if the brushes are free in their guides, cleaning all carbon deposits away with petrol or spirit, and if necessary ease the fit by lightly polishing the sides of the brush with a smooth file.

It is essential that replacement brushes are of the same grade as those originally specified for the machine.


The full travel of the armature is $\frac{31}{32}$ in. (24.6mm.). Check that the face of the flywheel ring of teeth is $\frac{1}{4}$ in. (3.2mm.) from the engaging face of the Starter Motor Pinion when it is in the idling position. If the Pinion teeth are badly worn the pinion should be renewed: before using the starter again, however, the teeth on the flywheel ring should be carefully examined for damaging burrs, and these cleaned off with a smooth file.

For details of major overhauls and inspections of the Dynamo and Starter, see the maker's booklets issued with the engine.


Electric Starter.

The clearance between the end of the Pinion on the Starter Motor and the side of the Gear Ring on the Flywheel should be $\frac{1}{16}$ in. to $\frac{3}{32}$ in.

If the Starter Motor Bracket is removed note should be made of the number of paper shims underneath the Bracket. The thickness of these shims controls the amount of backlash when the Pinion is meshed with the Gear Ring. This should be 0.015".



TACHOMETER AND INSTRUMENT PANEL



- A. Temperature Gauge.
- B. Tachometer.
- C. Oil Pressure Gauge.
- D. Temperature Gauge Capillary.
- E. Oil Pressure Gauge Pipe.
- F. Tachometer Drive Cable.
- G. Speed Control Arm (Short).
- H. Housing.
- J. Speed Control Lever.
- K. Starting Shaft.

Tachometer and Instrument Panel

AIR COMPRESSOR

The Air Compressor is driven by belt from a pulley behind the flywheel at the forward end of the engine and controlled by a hand operated clutch.

General Details.

Type W & J G1419A. Bore $1\frac{1}{8}$ ", Stroke 2". Displacement 1.5 cu.ft./mm. at 1080 R.P.M. either rotation. Max. pressure 450 p.s.i.

Lubrication.

By splash from sump in crankcase. Oil level checked by dipstick in end cover, or cock at side of crankcase. Remove breather for filling. Use good quality heavy oil S.A.E. 30 grade.

Valves.

Both valves are of special alloy steel. Care should be taken when replacing to ensure they are seating correctly when screwing down the plugs. The cylinder head should be removed after every three months' operation and thoroughly cleaned. When suction filter is fitted it should be cleaned every four weeks.

Cooling.

Cooling water is supplied from the engine system. Both outlets are connected by "Y" piece. The cooling water passing both sides of the delivery valve.

Arrangement.

There must be no stop-valve between the compressor and relief valve. It is advisable to fit a dirt and moisture trap in the delivery line close to the compressor.

Operation.

The compressor should always be unloaded when starting up by manipulating the unloader screw, and with the drain cock on the delivery line open. This ensures that all moisture is expelled from the system.

LISTER REVERSE GEAR

The reverse gear is built integral with the engine, incorporating a multiple plate ahead clutch, and an epicyclic reverse gear. Lubrication is from the engine system.

As the ahead clutch is of the metal to Ferodo plate type, it is most important that no "slip" should occur, as this involves loss of power and undue wear and tear of the plates. Slipping causes heat to be generated so that on the first sign of excessive heat while going ahead the boat should be stopped and the clutch adjusted. After adjustment a well defined neutral position must exist.

The Thrust Bearing is situated at the extreme after end of the reverse gearbox and is lubricated from the main oil circulating system. When a reduction gear is fitted the thrust races are mounted in the reduction gearbox.

Operation—Neutral.

Drive from the engine is passed initially from the Crankshaft Spur Gear (1) to the two Stepped Pinions (2). These in turn drive the two Spur Pinions (3), thus driving the Clutch Shaft Spur Gear (4). This latter is keyed to the Clutch Spider (5). The Clutch Shaft Spur Gear (4) is keyed to the Clutch Shaft (6), and while in neutral this gear remains at rest and the two sets of Pinions revolve around it, carrying around with them the Clutch Body (7).

Operation—Ahead.

Three Clutch Plates (Large) (8) have teeth on their outer periphery meshing with internal teeth on the Clutch Body (7), and two Clutch Plates (Small) (9) are keyed to the Clutch Spider (5). Pushing the control Lever forward rotates the Cross Shaft (10), throwing forward the Sliding Sleeve (11), and forcing the Toggle Levers (12) outward and forward. The Adjusting Screws (13) mounted in the Toggle Levers (12) then press upon the Clutch Gripping Plate (14) which, although keyed to the Clutch Spider (5), can slide forward pressing the Clutch Plates (8 and 9) together. Referring to the paragraph above (Neutral), as long as the engine is running the larger Clutch Plates (8) are being driven round by the Clutch Body (7). When the Control Lever is pushed forward, and the Toggle Levers (12) press all the Clutch Plates together friction then drives the two smaller ones, keyed to the Clutch Spider (5), which is keyed also to the Clutch Shaft Spur Gear (4) and the Clutch Shaft (6) itself, giving forward drive to the Gear Box Half Coupling (15). The Sliding Sleeve (11) is keyed to the Clutch Shaft (6) and so the Toggle Levers (12) and Gripping Plate (14) revolve at the same time, eliminating wear at these points.

Operation—Astern.


When the Control Lever is pulled aft, the Brake Band Roller Lever (16), operating through the Brake Band Lever (17) closes the Brake Band (18) around the Clutch Body (7) and holds it at rest. The drive from the engine then passes through the Stepped Pinions (2), and the Spur Pinions (3) and thus drives the Clutch Shaft Spur Gear (4) in the Astern direction of rotation. There is no applied pressure on to the Clutch Gripping Plate (14) so that the Clutch Spider (5) and the two Clutch Plates (Small) (9) drive round without transferring any drive to other components.

ADJUSTING THE LISTER REVERSE GEAR

Ahead.

With the Reverse Control Gear Lever in neutral, remove the inspection cover, and turn the sliding sleeve, carrying the toggle lever round, until one toggle lever is at the top. Slack off the adjusting screw locknut slightly and screw in the adjusting screw one quarter turn. Without losing this setting, set up the locknut hard. Turn the sliding sleeve until the other toggle lever comes on top, and repeat the adjustment, being careful to obtain equal adjustment on both toggle lever screws. Engage Ahead Clutch. There should be an appreciable effort required to get it in, (60-80 lbs. on the end of the reverse lever), but once in, there must be no tendency to jump out. It is important that there should be as little movement possible between the operating die and control sleeve with the gear fully engaged. With the Ferodo plates, "bedding in" of these takes place during the first few hours of operation and it is most important that the adjustment be followed up, until the clutch is fully "bedded in."

REVERSE GEAR




Astern.

Should there be any wear on the Brake Band the Gear will slip when engaged in astern. On the port side of the gear, under the Inspection Cover, an adjusting screw will be found on the Brake Band Lever over the tongue of the Brake Band. Put Hand Lever into neutral position, slacken the brake band lever adjusting screw locknut and adjust screw one $\frac{1}{4}$ turn in a clockwise direction and secure locknut. Put Hand Lever into the astern position. When gear is now engaged astern the same effect should be required to engage the gear as felt after adjusting the ahead clutch. Should the lever tend to jump out of engagement, ease the Brake Band adjustment when the gear is in the neutral position. Should the gear still slip in astern, tighten the Brake Band Lever Screw to suit.

Note.—Before adjustments are made to the reverse gear for ahead or astern running, the stop screws and locknuts on the locating plunger must be slackened off, and then secured when all adjustments have been made.

REDUCTION GEAR



J36

It is important to see that the correct lubricating oil is used in the reduction gear box, i.e., SAE 50 Oil when working in an air temperature below 85°F., and SAE 90 in tropical climates.


The level of oil in the casing should be examined daily at the same time as that in the lubricating oil tank, and the oil changed after every 450 hours running, the casing being thoroughly flushed out.

When an engine with reduction gear is to be laid up for any length of time, be careful to see that all cooling water is drained out of the reduction gear cooling jacket.

(On no account use grease as a lubricant in these boxes.)

ELECTRIC STARTING EQUIPMENT

WIRING DIAGRAM



DIMENSIONS OF WEARING PARTS AND SCHEDULE OF RENEWAL LIMITS

RECOMMENDED PERIOD FOR TOP OVERHAUL 1000 HOURS.

RECOMMENDED PERIOD FOR MAJOR OVERHAUL 3000/4000 HOURS.

GENERAL RECOMMENDATIONS ON WORKING CLEARANCE				Initial Clearance where applicable in 1/1000"	Clearance above which Replacement of one or both Parts is advisable in 1/1000"
Part No.	Component	Initial Size	Permissible wear in 1/1000"		
12-5-61 ... 10-2-4	Crankshaft End Journal ...	3" - 2 - 2½	2	4	10
10-2-5 ... 10-2-6A	End Main Bearings ...	3" + 2 + 3	3	4	
12-5-61 ...	Crankshaft Centre Journal ...	3" - 2 - 2½	2	4	10
12-5-13 ...	Centre Main Bearing ...	3" + 2 + 3	3	4	
12-5-61 ...	Crank Pin ...	3" - 2 - 2½	1	3	5
10-4-8 ...	Big End Bearing ...	3" + 1 + 1½	2	4	
12-6-1 ...	Camshaft Gear End Journal	2" - 1½ - 2½	3	1½	10
10-6-2 ...	Camshaft Gear End Bearing	2" + ½ + 1½	3	4	
12-6-1 ...	Camshaft Pump End Journal	1½" - 1½ - 2½	3	1½	10
10-6-3 ...	Camshaft Pump End Bearing	1½" + ½ + 1½	3	4	
12-6-1 ...	Camshaft Centre Journals ...	2½" - 2 - 3	3	1½	10
12-2-244 Crankcase	Camshaft Centre Bearing ...	2½" + 1 - ½	3	4	
10-4-3 ...	Gudgeon Pin ...	1½" ± .00015	1½	1	4
10-4-7 ...	Bush ...	1½" + 1 + 1½	1½	1½	
10-3-8A ... 10-3-181	Valve Stems ...	7/16" - 5 - 6	2	4½	10
10-3-39 ... 10-3-83	Valve Guides ...	7/16" ± ½	2	6½	

GENERAL RECOMMENDATIONS ON WORKING CLEARANCE				Initial Clearance where applicable in 1/1000"	Clearance above which Replacement of one or both Parts is advisable in 1/1000"
Part No.	Component	Initial Size	Permissible wear in 1/1000"		
10-2-56 ...	Valve Tappet ...	$\frac{5}{8}" - 1$	3	1	8
10-2-10 ...	Valve Tappet Guides ...	$\frac{5}{8}" - 1\frac{1}{2}$ $\frac{5}{8}" + 1$ $- 0$	3	$2\frac{1}{2}$	
10-4-61 ...	Piston Top Land ...	$4\frac{1}{2}" - 23$ $- 25$		25 27	18
10-4-61 ...	Piston 1st & 2nd Land ...	$4\frac{1}{2}" - 18$ $- 20$		18 22	
10-4-61 ...	Piston 3rd Land ...	$4\frac{1}{2}" - 14$ $- 16$		14 18	
10-4-61 ...	Piston Skirt ...	$4\frac{1}{2}" - 8$ $- 9$	5	8 11	
10-2-247 ...	Cylinder Liner ...	$4\frac{1}{2}" + 2$ $- 0$			
10-4-18 ...	Piston Ring Gap	$.0115/$ $.0165$		$11\frac{1}{2}$	40
614-888 ...	Piston Ring (Taper Side) Gap			$16\frac{1}{2}$	
10-4-18 ...	Piston Rings Width ...	$\frac{1}{8}" + 0$ $- 1$	4	2	12
10-4-61 ...	Piston Groove Width ...	$\frac{1}{8}" + 3$ $+ 2$		4	
23-2299 ...	Piston Scraper Ring Width ...	$3/16" - 5$ $- 6$	5		
23-2299 ...	Piston Scraper Groove ...	$- .0025$ $3/16" - .0015$		7 9	
11-13-639 & 40	Oil Pump Gears Outside Dia.	$1.70" - 2\frac{1}{4}$ $- 4$	3	2	8
11-13-280 ...	Oil Pump Body Bore ...	$1.70" + 1$ $- \frac{1}{4}$	3	5	
11-13-286 ...	Oil Pump Driving Spindle Dia.	$\frac{1}{4}" - \frac{1}{4}$ $- \frac{3}{4}$	3	$2\frac{1}{4}$	6
11-13-287 ...	Oil Pump Bush Bore ...	$\frac{1}{4}" + 2\frac{1}{4}$ $+ 3\frac{1}{2}$	3	$4\frac{1}{4}$	
/E61 ...	Crankshaft Big End Width ...	$3" + 5$ $+ 10$		4	
10-4-8 ...	Crankshaft Big End Bearing ...	$3" \pm 1$		11	

IMPORTANT

SPARE PARTS—Directions for Ordering

Always state **Engine No.**, **Part No.**, and **Description of Part** when ordering spares. The **Engine No.** will be found on brass plate attached to Crankcase and stamped on Flywheel Rim.

The Engine components have been divided into convenient groups and illustrated. **Do not** quote illustration Nos. when ordering.

INDEX TO PARTS LIST


	Page
Air Compressor	56
Air Receiver and Pipes	60
Air Start Valves	62
Camshaft, Bevel Gear and Governor	82
Centrifugal Circulating Water Pump	110
Crankcase	76
Crankcase End Cover	80
Crankshaft, Connecting Rod and Piston	
Cylinder Head and Change-over Valves—JPM	64
Cylinder Head—JKM	68
Cylinder Head Manifold Fittings	72
Dynamo	136
Electric Start Equipment	90
Fresh Water and Fuel Tanks	132
Flywheel and Raised Hand Starting	92
Fuel Filter	94
Fuel Injector and Pipes	98
Fuel Pump and Speed Control	96
Heat Exchanger	100
Instrument Panel	104
List of Joints—JP2MG/R & JP3MG/R	144
List of Joints—JK2MG/R & JK3MG/R	146
Lubricating Oil Pump and Strainer	108
Lubricating Oil Relief Valve, Tank and Pipes	106
Reduction Gear	128
Reverse Gear	122
Silencers	134
Starter	140
Seawater and Bilge Pump	118
Sea Water Pump	114
Special Tools	148
Temperature Control Valve (JKM only)	131

LIST OF PARTS

Air Compressor

Item No.	Description	Part No.	Cylinders	
			2	3
	Air Compressor less Flywheel	11-20-265	1	1
1	Crankcase	2401B	1	1
2	Cylinder	6135	1	1
3	Cylinder Head	3419A	1	1
4	Crankshaft	8754	1	1
5	Connecting Rod	8988	1	1
-	Big End Bush	9071	1	1
-	Little End Bush	9072	1	1
6	Piston	6116	1	1
7	Gudgeon Pin	5168B	1	1
8	End Pads	5169	2	2
9	Compression Rings	6114	2	2
10	Scraper Rings	6115	1	1
11	Marine Bearing Bush	2002	1	1
12	Cylinder Flange Gaskets	2069	1	1
13	Cylinder Head Gasket	6698	1	1
14	Front Cover Gasket	9631	1	1
15	Front Cover	7662	1	1
16	1/2" Gas Plug	11-13-198	1	1
17	Air Filter Body	4995	1	1
18	Spring Ring	2113	1	1
19	Filter Pad	4996	1	1
20	Perforated Disc Outer	2123	1	1
21	Perforated Disc Inner	2124	1	1
22	Banjo Pin	2234	1	1
23	Cylinder Head Joint Ring	9017/23	1	1
24	Suction Valve Plug	6137	1	1
25	Disc Valve	2672	1	1
26	Suction Valve Spring	2706	1	1
27	Cylinder Baffle Plate	3602	1	1
28	Front Cover Screw	4761/14	4	4
29	Spring Washers	9737/1	4	4
30	Locknut	4919/7	1	1
31	Union Collar	4602/3	1	1
32	Union Nut	4603/3	1	1
33	Delivery Valve Plug	3439S	1	1
34	Stud	SL2/45	4	4
35	Nut	4919/24	4	4
36	Delivery Valve Spring	SP1/7	1	1
37	Delivery Disc	2672	1	1
38	Cylinder Flange Stud	SL2/21	4	4
39	Nut	4919/24	8	8
40	Oil Drain Plug	8-2-6	1	1
41	Oil Regulator Plug (F.L. only)	6244	1	1
42	Plug	2014B	1	1
43	Oil Drain Plug Joint	5197	1	1
44	Compressor Support Bracket	11-13-347	1	1
45	Bolt to hold Compressor 3/8" x 1 1/8"	27-201	4	4
46	Nuts for ditto	27-6	4	4
47	Spring Washers for ditto	27-393	4	4
48	Support for Clutch Lever	11-13-729	1	1


AIR COMPRESSOR



Air Compressor--(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
49	Support Lock Nut	27-689	1	1
50	Flywheel for Compressor	13-19-219	1	1
51	Flywheel Key	27-2446	1	1
52	Pulley for Clutch	11-13-350	1	1
53	Driving Belt $\frac{1}{2}$ " x 5ft.	10-9-154	1	1
54	Clutch Lever	13-20-728	1	1
55	Clutch Lever Pawl	13-19-231	1	1
56	Pulley Bearing Housing	11-13-351	1	1
57	Fulcrum Screw for Pawl	11-14-665	1	1
58	Nuts for Fulcrum Pins	27-905	1	1
59	Return Spring for Clutch Pawl	11-14-664	1	1
60	Dowel	27-3797	1	1
61	Clutch Operating Collar	13-19-229	1	1
62	Clutch Operating Sleeve	11-13-353	1	1
63	Clutch Spring	1-323	1	1
64	Spring Retaining Washer	11-13-225	1	1
65	Felt Rings	27-1507	2	2
66	Cap Nut	27-1856	1	1
67	Lock Nut	27-1332	1	1
68	Stud for Crankshaft	27-33	1	1
69	Crankshaft Sleeve	13-23-66	1	1
70	Fulcrum Pin for Collar	13-19-230	2	2
71	Nuts for Fulcrum Screws	27-235	2	2
72	Ball Bearing	1-7	1	1
73	Clutch Operating Sleeve Nut	11-13-354	1	1
74	Clamping Washer	13-23-67	1	1
75	Bearing Housing to Clutch Pulley Screw	27-888	4	4
76	Taper Pin	27-454	1	1
77	Clutch Lever Fulcrum Pin	13-20-729	1	1
78	Split Pins	27-123	2	2
79	Clutch Lever Knob	31-967	1	1
80	Stop Pin	27-204	1	1
81	Compressor Water Drain Tap	1-610	1	1
82	Joint for Water Drain Tap	5197		
83	Engine Flywheel Pulley Setscrews $\frac{5}{16}$ " x $1\frac{1}{2}$ "	27-2093	4	4
84	Engine Flywheel Pulley	11-13-727	1	1
85	Water Pipe "T" Piece	11-13-357	1	1
86	Water Pipe Joint	3306	1	1
87	Water Pipe Elbow	3411	1	1
88	Washers	27-545	1	1
89	Screw (Compressor Bracket to Engine Support Bracket) $\frac{5}{8}$ " x $1\frac{1}{4}$ "	27-641	1	1
90	Screw (Compressor Bracket to Engine Support Bracket) $\frac{5}{8}$ " x $1\frac{1}{4}$ "	27-63	2	2
91	Washer for Ditto	27-395	1	1
92	Washer for Ditto	27-394	2	2
93	Water Pipe Inlet to Compressor	12-13-952	1	1
94	Water Pipe Outlet from Compressor	12-13-953	1	1
95	Joint for Water Pipe Unions	12406	4	4
96	Compressor Water Pipe Unions	12427	4	4
97	Water Outlet "Y" Piece	3786	2	2
98	Rubber Hose Connections	3861	1	1
99	Water Outlet Pipes	3859	1	1
100	Hose Clip Wire $\frac{5}{16}$ " x $1\frac{1}{2}$ "	27-2903	4	4

AIR COMPRESSOR




Air Receiver and Air Pipes

Item No.	Description	Part No.	Cylinders	
			2	3
	AIR BOTTLE complete with valves, etc.	13-22-263c	1	1
1	Air Bottle	13-22-263	1	1
2	4-way Branch	11-22-348	1	1
3	Connection	13-19-88	4	4
4	Outlet Union to Pressure Gauge	12427	1	1
5	Adaptor for Pressure Gauge	11-23-9	1	1
6	Pressure Gauge	10-19-47	1	1
7	Wheel Valve	13-19-93	2	2
8	Adaptor for Relief Valve	13-20-725	1	1
9	1" Wheel Valve	11-22-346	1	1
10	Complete Relief Valve	27-1870	1	1
11	Outlet Connection in Wheel Valve $\frac{3}{4}$ " x $\frac{1}{2}$ " BSP	13-19-94	1	1
12	Fusible Plug Adaptor $1\frac{1}{2}$ " BSP x $\frac{1}{2}$ " BSP	11-22-986	1	1
13	Fusible Plug	11-22-308	1	1
14	Union $\frac{1}{4}$ " BSP for Drain Valve	103-106	1	1
15	Joint Ring	13-21-777	2	2
16	Joint Ring	13-21-778	12	12
17	Joint Ring for Drain Plug	13-22-350	3	3
18	Drain Plug	11-13-693	1	1
19	Valve $\frac{1}{4}$ " BSP for Drain	13-22-928	1	1
20	Outlet Union $1\frac{1}{4}$ " x 1" BSP	11-22-330	1	1
21	Joint for Wheel Valve	13-21-787	2	2
22	Air Pipe, Compressor to Relief Valve 10 m/m. x 6ft.	13-19-85	1	1
23	Air Pipe, Air Bottle to Starting Valve $\frac{3}{8}$ " O/D x 6ft.	13-19-95	1	1
24	Air Pipe, Starting Valve to No. 1 Cylinder Head Compression Change-over Valve JPM only	13-19-245	-	1
	Air Pipe, Starting Valve to No. 1 Cylinder Head JKM only	11-23-850	1	-
25	Air Pipe, Starting Valve to No. 2 Cylinder Head Compression Change-over Valve JPM only	11-19-245	1	-
	Air Pipe, Starting Valve to No. 2 Cylinder Head JKM only	12-23-850	-	1
26	Union Nut for Air Pipe	13-19-99	1	1
27	Union Nut for Charging Pipe	13-19-132	1	1
28	Union Nipple for Charging Pipe	13-19-131	1	1
	*Copper Joint Washer $1\frac{1}{4}$ " BSP x .020"	11-22-993	As reqd.	
	*Copper Joint Washer 1" BSP x .020"	11-22-994	As reqd.	
	*Copper Joint Washer $\frac{1}{2}$ " BSP x .020"	11-22-995	As reqd.	

*These Washers are used in conjunction with Items 15-16-21 to adjust position of Valves and Adaptors.


AIR RECEIVER AND AIR PIPES



Air Starting Valves

Item No.	Description	Part No.	Cylinders	
			2	3
	AIR STARTER VALVE complete	11-20-270C	1	1
1	Valve Body	12-19-164	1	1
2	Valve	12-19-165	1	1
3	Valve Lever	12-19-166	1	1
4	Fulcrum Pin for Lever	12-19-167	1	1
5	Split Pin for Fulcrum Pin	27-122	2	2
6	Spring for Lever	12-19-172	1	1
7	Button for Lever	11-19-782	1	—
8	Button for Lever	8-2-130	—	1
9	Adjusting Screw for Lever	27-62	1	1
10	Lock Nut for Adjusting Screw	27-18	1	1
11	Spring for Valve	10-20-355	1	1
12	Nut for Inlet Union	13-19-99	1	1
13	Set Screws for Valve Body JP only	27-38	2	2
14	Nipple for Inlet Union	13-19-98	1	1
15	Union for Air Pipe to Cylinder Head	13-19-94	1	1
16	Union Joint	13-21-778	1	1
17	Union for Air Pipe from Bottle	12-19-258	1	1
18	Union Joint	13-21-787	1	1
19	Cam for Air Starter Valve JPM only	11-19-781	1	—
20	Cam for Air Starter Valve JPM only	12-19-168	—	1
	Cam for Air Start Valve JKM only	11-23-843	1	—
	Cam for Air Start Valve JKM only	12-23-843	—	1
21	Woodruff Key JPM only	27-566	1	1
22	Lock Nut for Cam JPM only	12-19-169	1	1
23	Spring Washer JPM only	27-2061	1	1
	Mounting Plate JKM only	11-23-846	1	1
	Woodruff Key JKM only	27-107	1	1
	Oil Seal JKM only	27-4536	1	1
	Bolt $\frac{3}{8}$ " Whit. JKM only	27-4528	1	1
	Air Start Drive Assembly JKM only	11-23-847	1	1
CHANGE-OVER VALVE (JPM only) VALVE FOR COMPRESSED AIR STARTING				
24	Combustion Chamber Main Plug	10-8-140	1	1
25	Joint between Main Plug and Cylinder Head	10-3-91	1	1
26	Combustion Chamber Auxiliary Plug	12-19-175	1	1
27	Joint Ring between Plugs	10-3-6	1	1
28	Combustion Chamber Change-over Valve	10-19-731	1	1
29	Combustion Chamber Valve Spring Valve	11-19-777	1	1
30	Combustion Chamber Valve Spring Collar	10-19-728	1	1
31	Taper Pin for Valve Spring Collar	27-613	1	1
32	Combustion Chamber Nut	10-19-724C	1	1
33	Combustion Chamber Cap Nut	10-19-725	1	1
34	Handwheel and Screw complete	10-3-68BC	1	1
35	Push Rod for Handwheel	10-19-737	1	1
36	End Washer for Push Rod	10-19-730	1	1
37	Leather Washer for Push Rod	10-19-729	1	1
38	End Boss for Push Rod	10-19-732	1	1
39	Lock Nuts for Push Rod	27-235	2	2
40	Bush for Change-over Valve	12-19-196	1	1
41	Joint Ring for Connector	102-91	2	2
42	Swivel Connector for Air Pipe	10-19-726	1	1
—	Combustion Chamber Nut (JKM only)	616-1639	1	1

AIR STARTING VALVES




U40

Cylinder Head and Change-Over Valve JPM only

Item No.	Description	Part No.	Cylinders	
			2	3
	CYLINDER HEAD (Studded)	10-3-170S	2	3
	With Studs, Plugs and Valve Guides only, comprising the following parts :—			
1	Cylinder Head	10-3-170	2	3
2	Cylinder Head Stud for Cover	27-736	2	3
3	Cylinder Head Stud for Injector	27-769	4	6
4	Cylinder Head Valve Guide (Inlet)	10-3-39	2	3
5	Cylinder Head Valve Guide (Exhaust)	10-3-83	2	3
*6	Combustion Chamber Main Plug	10-3-90	2	3
*7	Combustion Chamber Main Plug Joint	10-3-91	2	3
	(*These two items are not included with C.O.V. assembly 8-1/C5AC and if required must be ordered separately.)			
	CYLINDER HEAD with above fittings and complete with Valves, comprising :—	10-3-170C	2	3
8	Cylinder Head Inlet Valve	10-3-8A	2	3
9	Cylinder Head Exhaust Valve	10-3-121	2	3
10	Valve Split Collets (pairs)	10-3-25	8	12
11	Cylinder Head Valve Spring (Inner)	12-3-219	4	6
12	Cylinder Head Valve Spring (Outer)	12-3-129	4	6
13	Cylinder Valve Spring Carrier	10-3-130	4	6
14	Cylinder Valve Cap	10-3-23	4	6
	CYLINDER HEAD complete with compression ratio change-over valve, valve rockers and valve push rod, same as 10-3-170C and including the following parts :—	10-3-170CR	2	3
15	Valve Rocker with Bush (JPM & JKM)	10-3-13AB	4	6
16	Valve Rocker Bush (JPM & JKM)	10-3-14A	4	6
17	Valve Rocker Striking Pin (JPM & JKM)	10-3-15	4	6
18	Valve Rocker Adjusting Screw (JPM & JKM)	26-98	4	6
19	Valve Rocker Adjusting Screw Locknut	27-714	4	6
20	Valve Rocker Shaft with Plug	11-3-298	2	3
	Valve Rocker Plug	29-98	2	3
21	Valve Rocker Shaft Greaser	27-606	2	3
	Valve Rocker Shaft Elbow	27-462	—	1
	Valve Rocker Shaft Nipple	27-463	—	2
22	Valve Rocker Distance Collar	10-3-18	2	3
	Valve Rocker Shaft Greaser Socket	27-9	—	1
23	Valve Rocker Set Screw	27-150	2	3
	Valve Rocker Assembly	10-3-171	2	2
	Valve Rocker Assembly	12-3-171	—	1
24	Valve Push Rod	10-3-20AC	4	6
	CYLINDER HEAD with valves, rockers and compression change-over valve complete	10-3-170	2	3
	(as 10-3-170CR but with the following additional parts) :—	CRCV		
	Compression Ratio Change-over Valve complete comprising :	10-3-5AC	2	3
25	Valve Spindle	10-3-5A	2	3
26	Valve Spring	10-3-11	2	3
27	Valve Handwheel, comprising :	10-3-68BC	2	3
	Handwheel	10-2-224		
	Centre	10-3-245		
	Dowel	27-1224		


CYLINDER HEAD AND CHANGE OVER VALVE JPM only



Cylinder Head and Change-Over Valve-(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
28	Valve Handwheel Key	27-107	2	3
29	Valve Handwheel Nut	27-235	4	6
30	Valve Handwheel Spring Washer	27-1063	2	3
31	Valve Instruction Plate	27-3990	2	3
32	Valve Instruction Plate Screw	27-48	4	6
33	Combustion Chamber Auxiliary Plug	10-3-3	2	3
34	Combustion Chamber Nut	10-3-4A	2	3
35	Combustion Chamber (Aux.) Joint Ring	10-3-6	2	3
DECOMPRESSOR				
36	Decompressor Body	13-14-411	2	3
37	Decompressor Cam	13-14-412	2	3
38	Decompressor Plunger	13-14-413	2	3
39	Decompressor Cam Spindle	13-14-414	2	3
40	Decompressor Lever	13-14-415	2	3
41	Decompressor Locknut	13-14-416	2	3
42	Decompressor Main Spring	13-14-417	2	3
43	Decompressor Auxiliary Spring	13-14-418	2	3
44	Decompressor Dowel Pin	27-2069	2	3
45	Decompressor Locking Screw	27-204	2	3
46	Cylinder Head Cover Cap Nut	27-1974	2	3
FUEL INJECTOR				
47	Fuel Injector, complete	616-2144	2	3
—	Fuel Injector Nozzle Body and Valve	616-2145	2	3
48	Fuel Injector Flange	10-3-31	2	3
49	Fuel Injector Flange Nut $\frac{7}{16}$ " Whit.	27-5	4	6
50	Fuel Injector Nozzle C.A. Joint	10-3-41	3	6

CYLINDER HEAD AND CHANGE OVER VALVE JPM only




141

Cylinder Head JKM only

Item No.	Description	Part No.	Cylinders	
			2	3
	CYLINDER HEAD (Studded)	11-3-290S	2	3
	With Studs, Plugs and Valve Guides only, comprising the following parts :—			
1	Cylinder Head	11-3-290	2	3
2	Water Pipe Ferrule Assy.	11-3-299	2	3
3	Water Pipe Restrictor	11-3-294	6	9
4	Stud for Cylinder Head Cover	27-736	2	3
5	Stud for Injector	27-769	4	6
6	Cylinder Head Valve Guide (Inlet)	10-3-39	2	3
7	Cylinder Head Valve Guide (Exhaust)	10-3-83	2	3
8	Combustion Chamber Main Plug	11-3-305	2	3
9	Combustion Chamber Sealing Plug	8-3-179	2	3
10	Combustion Chamber Main Plug Joint	10-3-91	2	3
	CYLINDER HEAD with above fittings and complete with Valves, comprising :—	11-3-290C	2	3
11	Inlet Valve	10-3-8A	2	3
12	Exhaust Valve	10-3-121	2	3
13	Valve Split Collets (pairs)	10-3-25	8	12
14	Valve Spring (Inner)	12-3-219	4	6
15	Valve Spring (Outer)	12-3-129	4	6
16	Valve Spring Carrier	10-3-130	4	6
17	Valve Cap	10-3-23	4	6
	CYLINDER HEAD complete with combustion chamber valve, valve rockers and valve push rods, same as 11-3-209C and including the following parts :—	11-3-290CR	2	3
18	Valve Rocker with Bush	10-3-13AB	4	6
19	Valve Rocker Striking Pin	10-3-15	4	6
20	Valve Rocker Adjusting Screw	26-98	4	6
21	Valve Rocker Adjusting Screw Locknut	27-714	4	6
22	Valve Rocker Shaft	11-3-298	2	3
23	Valve Rocker Bush	10-3-14A	4	6
24	Valve Rocker Setscrew	27-150	6	8
25	Valve Rocker Shaft End Plug	11-3-303	2	3
26	Valve Rocker Shaft End Plug Joint	12406	2	3
27	Plug	11-3-295	2	3
28	Joint	11-3-296	2	3
29	Union	291-2114/1	2	3
30	Joint	600-106	2	3
31	Valve Push Rod	10-3-20AC	4	6
32	Cylinder Head Cover	13-14-419	2	3
33	Cylinder Head Cover Joint	11-3-291	2	3
34	Cylinder Head Cover Cap Nut	27-1974	2	3


CYLINDER HEAD-JKM only



Cylinder Head-JKM only--(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
DECOMPRESSOR				
36	Decompressor Body	13-14-411	2	3
37	Decompressor Cam	13-14-412	2	3
38	Decompressor Plunger	13-14-413	2	3
39	Decompressor Cam Spindle	13-14-414	2	3
40	Decompressor Lever	13-14-415	2	3
41	Decompressor Locknut	13-14-416	2	3
42	Decompressor Main Spring	13-14-417	2	3
43	Decompressor Auxiliary Spring	13-14-418	2	3
44	Decompressor Dowel Pin	27-2069	2	3
45	Decompressor Locking Screw	27-204	2	3
FUEL INJECTOR				
46	Fuel Injector, complete	616-2144	2	3
—	Fuel Injector Nozzle Body and Valve	616-2145	2	3
47	Fuel Injector Flange	10-3-31	2	3
48	Fuel Injector Flange Nut $\frac{1}{8}$ " Whit.	27-5	4	6
49	Fuel Injector Nozzle C.A. Joint	10-3-41	3	6


CYLINDER HEAD-JKM only



Cylinder Head Manifold Fittings

Item No.	Description	Part No.	Cylinders 2	Cylinders 3
CYLINDER HEAD FITTINGS				
1	Cylinder Head Nuts for Stud	27-1192	12	18
2	Cylinder Head Nut for Tubular Stud	27-794	4	6
3	Cylinder Head Washer for Tubular Stud	27-795	4	6
4	Cylinder Head Gasket	10-3-105	2	3
5	Cylinder Head Copper Shim } Not supplied separately ...	10-3-179	2	3
6	Cylinder Head Cover	13-14-419	1	2
7	Cylinder Head Cover (For'd) Raised Starting	13-14-420	1	1
	Cylinder Head Cover Nut	27-1974	2	3
8	Cylinder Head Instruction Plate	27-2449	1	1
9	Cylinder Head Instruction Plate Dowel	27-707	4	4
10	Inlet and Exhaust Flange Joint	10-3-57	4	6
11	Air Inlet Manifold	11-3-29	1	-
	Air Inlet Manifold	12-3-29	-	1
12	Air Silencer	11-13-62	1	1
13	Water Cooled Exhaust Manifold	11-13-202	1	-
	Water Cooled Exhaust Manifold	12-13-202	-	1
14	Water Cooled Exhaust Manifold Expansion Plug	27-768	3	3
15	Water Cooled Exhaust Manifold Drain Plug	21-153	3	1
16	Joint	5197	1	1
17	Cylinder Head Water Outlet Pipe	13-13-886	1	-
	Cylinder Head Water Outlet Pipe	12-13-470	-	1
	Cylinder Head Water Outlet Pipe Joint	10-2-59	2	3
18	Inlet and Exhaust Manifold Stud	27-57	6	9
	Water Cooled Exhaust Manifold Stud (long)	27-648	2	3
	Cylinder Head Water Outlet Pipe	12-13-872	-	1
	Expansion Plug	27-757	1	1
	Cylinder Head Water Outlet Pipe Tee (JPM only)	12-22-126	1	3
	Cylinder Head Water Outlet Pipe Union (JPM only)	11-13-268	1	1
19	Cylinder Head Exhaust and Inlet Nuts	27-1974	8	12
20	Setscrews, Silencer to Manifold $\frac{3}{8}$ " x $1\frac{1}{8}$ " Whit.	27-68	2	2
21	Setscrews, Silencer to Manifold $\frac{3}{8}$ " x 2" Whit.	27-38	2	2
—	Water Jet Pipe Assy. (JKM only)	11-3-299	2	3
—	Water Inlet Restrictor (JKM only)	11-3-294	6	9
—	Pipe Connecting Plug (JKM only)	11-3-295	2	3
—	Pipe Connecting Plug Joint (JKM only)	11-3-296	2	3
—	Cylinder Head Plug (JKM only)	11-3-303	2	3
—	Cylinder Head Plug Joint (JKM only)	12406	2	3
—	Union for Oil Pipe	291-2114/1	2	3
—	Camshaft to Rockershaft Oil Pipe Assembly (JKM only)	11-15-495	1	-
		12-15-495	-	1
—	Fixing Screw (JKM only)	11-2-478	1	1
—	Fixing Screw Joint (JKM only)	5197	2	2
—	Adaptor Plug for Oil Pipe (JKM only)	11-2-479	1	1
—	"O" Ring for Plug (JKM only)	201-13120	2	2
—	Plug for Oil Drain Passage (JKM only)	11-3-307	1	1
—	Cylinder Head Low Joint (JKM only)	11-3-291	2	3
22	Exhaust Silencer to Manifold Joint	11-13-206	1	1
23	Exhaust Silencer Body	11-13-895	1	1
24	Exhaust Silencer Control Side Cover	11-13-369	1	1
25	Exhaust Silencer Cover (without Control)	11-13-875	1	1
26	Exhaust Silencer Body Expansion Plug	27-801	9	9
27	Exhaust Silencer Outlet Cover	11-13-148	1	1


CYLINDER HEAD MANIFOLD FITTINGS



Cylinder Head Manifold Fittings--(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
28	Exhaust Pipe Flange	10-13-158	1	1
29	Exhaust Pipe Flange Joint	11-13-422	1	1
30	Exhaust Pipe Flange Setscrew	27-647	4	4
31	Cylinder Head Water Temperature Regulating 3-way Cock (JPM only)	11-13-468	1	1
	Cylinder Head Pipe 3-way Cock to Tee Piece (JPM only)	11-13-872	1	1
	Cylinder Head Water Outlet Pipe Joint	10-2-59	2	3
	Vent Tap Plug	11-13-452	1	1
	Vent Tap Plug Joint	3306	1	1
	Vent Tap	5137	1	1
	Vent Tap Joint	5197	1	1
	Water Outlet Manifold Plug	21-153	1	1
	Water Outlet Manifold Plug Joint	5197	1	1
	Union Connection (JPM only)	11-13-251	2	2
	Union Connection Joint (JPM only)	3306	5	5
	Water Outlet Pipe to Cock	11-13-871	1	1
	Water Outlet Pipe Nut (JPM only)	65-103	1	1
	Water Outlet Pipe Nipple (JPM only)	11-13-252	1	1
	Water Outlet Pipe Joint (JPM only)	12419	5	5
	Flange Extension Piece 1½" bore Joint	11-15-568	1	1
	Joint	3309	2	2
	Raw Water Delivery Pipe (Manifold end)	11-15-552	1	-
	By Pass Pipe	11-15-559	1	-
	By Pass Pipe	12-15-559	1	-
	Raw Water Delivery Pipe (Manifold end)	12-15-559	-	1


CYLINDER HEAD MANIFOLD FITTINGS



Crankcase

Item No.	Description	Part No.	Cylinders	
			2	3
1	Crankcase with Studs (JP2M up to December 1959) ...	11-13-921S	1	-
1	Crankcase with Studs (JP3M up to December 1959) ...	12-13-921S	-	1
-	Crankcase with Studs (JP2M, JK2M) ...	11-15-494S	1	-
-	Crankcase with Studs (JP3M, JK3M) ...	12-15-494S	-	1
2	Stud for For'd Starting Bracket (Raised Starting only)—10 $\frac{1}{4}$ "	27-1315	2	2
3	Stud for End Cover ...	27-35	7	7
4	Nut for End Cover ...	27-4	7	7
5	Stud for End Cover ...	27-536	2	2
6	Nut for End Cover ...	27-6	2	2
7	Stud for Tappet Bracket ...	27-214	4	6
8	Nut for Tappet Bracket ...	27-6	4	6
9	Spring Washer ...	27-393	4	6
10	Stud for Doors ...	27-33	20	28
11	Stud for Crankshaft Bearing ...	27-50	3	3
12	Nut ...	27-6	3	3
13	Stud for Water Flange ...	27-50	2	2
14	Stud for Cylinder Head ...	27-1190	10	16
15	Stud (for Cylinder Head (Tubular) ...	11-2-459	4	6
16	Stud for Camshaft Bush ...	27-65	2	2
17	Stud for Water Cooled Silencer ...	27-1519	2	2
	Nut for Water Cooled Silencer ...	27-26	2	2
	Washer for Water Cooled Silencer ...	27-807	2	2
18	Crankcase Bush for Camshaft ...	10-6-2	1	1
19	Camshaft Bush Locating Screw ...	11-2-55	1	1
20	Joint for Camshaft Bearing Locating Screw ...	10-2-180	1	1
21	Camshaft Bush for Pump End ...	10-6-3	1	1
22	Camshaft Bush Nut 5/16" Whit. ...	27-7	2	2
23	Camshaft Bush Spring Washer ...	27-413	2	2
-	Crankcase Support Bracket (2 cyl.) Port ...	11-13-762	1	-
-	Crankcase Support Bracket (2 cyl.) Starboard ...	11-13-763	1	-
24	Crankcase Support Bracket (3 cyl.) Port ...	12-13-762	-	1
25	Crankcase Support Bracket (3 cyl.) Starboard ...	12-13-763	-	1
26	Crankcase Support Bracket Stud $\frac{3}{4}$ " Whit. x 4 $\frac{1}{8}$ " ...	13-14-192	4	6
27	Crankcase Support Bracket Nut $\frac{3}{4}$ " ...	27-2	4	6
28	Crankcase Support Spring Washers ...	27-396	6	6
29	Crankcase Water Drain Tap ...	27-128	1	1
	Crankcase Water Drain Plug ...	12407	1	-
	Crankcase Water Drain Plug Joint ...	12406	2	1
30	Crankcase Water Flange ...	102-296	1	1
31	Crankcase Water Flange Joint ...	10-2-59	3	4
32	Crankcase Water Flange Nut $\frac{3}{8}$ " Whit. Dome ...	27-1974	2	2
33	Crankcase Oil Drain Plug ...	10-13-132	1	1
34	Crankcase Oil Drain Plug Joint ...	3306	1	1
35	Crankcase Door (Small) ...	11-13-469	-	1
36	Crankcase Door (Small for Filter) ...	10-2-257	1	1
37	Stud for Filter ...	27-1579	4	4
38	Nut for Filter Stud ...	27-906	4	4
39	Crankcase Door (Small for Vent Pipe) ...	11-13-735	1	1
-	Crankcase Door (Large) (JP2M only) ...	11-2-454	1	-
-	Crankcase Door (Large) (JK2M only) ...	11-2-407	1	-
40	Crankcase Door (Large) (JP3M only) ...	12-2-407	-	1
-	Crankcase Door (Large) (JK3M only) ...	12-2-454	-	1
41	Crankcase Door Gearside ...	11-2-19AS	1	1

CRANKCASE




Crankcase-(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
42	Crankcase Door Joint (Small)	10-2-61A	2	3
	Crankcase Door Joint (Large)	10-2-68	1	-
—	Crankcase Door (Small) for Filter	10-2-257	1	-
43	Crankcase Door Joint (Large)	12-2-68	-	1
44	Crankcase Door Joint (Gearside)	11-2-60	1	1
45	Crankcase Door Nut 5/16" Whit. Dome	27-1856	20	28
46	Crankcase Oil Filler Blank Flange	11-13-396	1	1
47	Crankcase Oil Filler Lid Screw	27-150	2	2
48	Crankcase Engine Specification Plate	27-666	1	1
49	Crankcase Engine Specification Plate Dowel	27-707	4	4
50	Crankcase Dowel for Cylinder Head	10-2-110	4	6
51	Crankcase Dowel for Door	27-1087	2	3
52	Lifting Eyebolt $\frac{1}{2}$ " B.S.F.	27-3697	4	4
53	Register Ring for Reverse Gearcase	11-13-575	1	1
54	Stud Crankcase—Rev. Gearcase	27-55	6	6
55	Cap Nut for Stud	27-708	6	6
56	Setscrew Register Ring to Crankcase	27-203	4	4
57	$\frac{1}{2}$ " Union for Crankcase Door	12427	1	1
58	Union Joint	12406	1	1
59	Oil Pressure Gauge Pipe Union	103-106	1	1
	Oil Pressure Gauge Pipe Washer	5197	1	1
BREATHER complete, JPM and JKM, comprising :—		10-2-245c	1	1
60	Breather Plate	10-2-245	1	1
61	Breather Plate Dowel	27-655	1	1
62	Breather Disc	21-112	-	1
63	Breather Cover	21-113	1	1
64	Breather Spacing Bush	21-114	1	1
65	Breather Cover Screw	27-1285	1	1
66	Breather Plate Screw	27-1552	3	3
67	Governor Rod Bush	11-6-18	1	1

**ALWAYS QUOTE ENGINE
NUMBER
WHEN ORDERING SPARES**

CRANKCASE



Crankcase End Cover

Item No.	Description	Part No.	Cylinders	
			2	3
1	END COVER with Studs	10-2-3AS	1	1
2	End Cover Stud for Fuel Pump Bracket	27-194	2	2
3	End Cover Stud for Bevel Wheel Housing	27-45	2	2
4	End Cover Stud for Governor Lever Support Flange	27-33	2	2
5	End Cover Stud for Dust Cover	27-37	4	4
6	End Cover Bevel Wheel Bush (Fuel Pump)	10-2-238 -	1	1
7	End Cover Bevel Wheel Dowel	27-1224	1	1
8	End Cover Bevel Wheel Oil Thrower	10-2-37 -	1	1
9	End Cover Bevel Wheel Housing	10-2-93	1	1
10	End Cover Bevel Wheel Housing Joint	10-2-114	1	1
11	End Cover Bevel Wheel Housing Nut $\frac{3}{8}$ " Whit.	27-6	2	2
12	End Cover Main Bearing Dowel	10-2-231	1	1
13	End Cover Joint	10-2-63	1	1
14	End Cover Nut $\frac{3}{8}$ " Whit.	27-6	2	2
15	End Cover Nut $\frac{1}{2}$ " Whit.	27-4	7	7
16	End Cover Ratchet Wheel Spigot	11-13-404	1	1
17	End Cover Dust Cover Joint	10-2-64A	1	1
18	End Cover Oil Seal	27-1739	1	1
19	Felt Washer	10-2-9	1	1
20	Union for Lub. Oil Pipe	10-2-85	1	1
21	Union Tab Washer	10-2-64	1	1
—	Bevel Wheel Cover (JKM only)	10-2-32	1	1 †
—	Bevel Wheel Cover Joint (JKM only)	10-2-65	1	1
—	End Cover Governor Lever Support Flange (JKM only)	10-2-33	1	1
—	End Cover Governor Lever Support Joint (JKM only)	10-2-67A	1	1

†NOT used with Air Starting.

**ALWAYS QUOTE ENGINE
NUMBER
WHEN ORDERING SPARES**

This technical drawing is an exploded view of a mechanical assembly, likely a pump or valve component. The parts are numbered 1 through 21. The main body (1) is a complex casting with a central cavity (5) and a side port (3). It is mounted on a base (13) via a bracket (2). A cylindrical component (16) is shown above the main body, with a gasket (17) between them. A smaller cylindrical part (12) is also shown. Various bolts (15), nuts (14), and washers (18) are used for assembly. A small pin (4) is shown near the base. The diagram illustrates the spatial relationship and assembly sequence of the components.


Camshaft, Bevel Gear and Governor

Item No.	Description	Part No.	Cylinders	
			2	3
	Camshaft complete (JP2M only) comprising	11-6-1c	1	-
	Camshaft complete (JP3M only) comprising	12-6-1c	-	1
	Camshaft Bare (JP2M only)	11-6-1a	1	-
1	Camshaft Bare (JP3M only)	12-6-1a	-	1
	Camshaft complete (JK2M)	11-6-197c	1	-
	Camshaft complete (JK3M)	12-6-197c	-	1
	Camshaft Bare (JK2M)	11-6-197	1	-
	Camshaft Bare (JK3M)	12-6-197	-	1
2	Camshaft Gear Wheel	10-6-4	1	1
3	Camshaft Gear Wheel Key	10-6-5	1	1
4	Camshaft Gear Wheel Locating Plate	10-6-6	1	1
5	Camshaft Gear Wheel Tab Washer	10-6-64	1	1
6	Camshaft Plug	10-6-46	2	2
	Camshaft Governor Weight (1000 R.P.M.)	10-6-7A	2	2
7	Camshaft Governor Weight (1200 R.P.M.)	10-6-70	2	2
	Governor Weight 1500 R.P.M.	11-6-198	2	2
8	Camshaft Governor Weight Fulcrum Pin	10-6-103	2	2
9	Camshaft Governor Weight Fulcrum Split Pin	27-911	4	4
10	Camshaft Bevel Wheels (Set of Three)	10-2-341	3	3
	Camshaft Bevel Wheels (Set of Three)—Air Start	11-2-474	1	1
11	Camshaft Bevel Wheel Key	10-6-35	1	1
12	Camshaft Bevel Wheel Washer	10-6-49	1	1
13	Camshaft Bevel Wheel Tab Washer	10-6-64	1	1
14	Valve Tappet	10-2-56	4	6
15	Valve Tappet Bracket	10-2-10	2	3
16	Valve Tappet Bracket Lockwasher	10-6-66	4	6
17	Valve Tappet Bracket Nut $\frac{1}{2}$ " Whit.	27-6	4	6

GOVERNOR

	Governor Speeder Spring (850-1000 R.P.M.)	10-6-60	1	1
18	Governor Speeder Spring (Over 1000 R.P.M.)	10-6-59	1	1
19	Governor Speeder Spring Hook	10-14-613	1	1
20	Governor Speeder Spring Adjusting Nut	3177	1	1
21	Governor Speeder Spring Locknut	27-15	1	1
22	Governor Speeder Spring Anchor Pin	1-240	1	1
	Bracket for Anchor Pin	11-15-604	1	1
23	Governor Speeder Spring Anchor Pin Nut $\frac{5}{16}$ " Whit.	27-7	1	1
24	Governor Inside Lever with Bearing Pad	10-6-12c	1	1
25	Governor Inside Lever Bearing Pad	27-787	2	2
26	Governor Inside Lever Fulcrum Pin	10-6-13	1	1
27	Governor Inside Lever Fulcrum Split Pin	27-123	2	2
28	Governor Inside Lever Fulcrum Pin Washer	27-82	2	2
29	Governor Inside Lever Fork	10-6-40	1	1
30	Governor Inside Lever Fork Taper Pin	27-237	1	1
31	Governor Inside Lever Bracket	10-6-15A	1	1
32	Governor Inside Lever Bracket Joint	10-6-48A	1	1
33	Governor Inside Lever Bracket Set Pin	27-150	4	4
	Governor Spindle (JP)	11-6-16	1	-
34	Governor Spindle (JK)	12-6-16	-	1
	Governor Spindle Bush	11-6-18	-	1
35	Governor Spindle Plug	11-6-45	2	2
36	Governor Sleeve	10-6-20	1	1
	Governor Adjusting Link	31-1422	1	1


CAMSHAFT BEVEL GEAR AND GOVERNOR



Camshaft Bevel Gear and Governor-(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
37	Governor Bell Crank Lever	11-15-603	1	1
38	Governor Bell Crank Lever Ball Bearing	10-6-51	2	2
39	Governor Bell Crank Lever Fulcrum Pin	10-6-39A	1	1
40	Governor Bell Crank Lever Collar	10-6-42	1	1
41	Governor Bell Crank Lever Collar Split Pin	27-236	1	1
42	Governor Bell Crank Lever Support Flange	10-2-33B	1	1
43	Governor Bell Crank Lever Support Flange Joint	10-2-67A	1	1
44	Governor Bell Crank Lever Support Flange Nut	27-7	2	2
45	Governor Bell Crank Lever Stop (Long) Pin	10-6-71	1	1
46	Governor Bell Crank Lever Stop (Short) Pin	10-6-72	1	1
47	Governor Bell Crank Lever Stop	10-6-68	1	1
48	Governor Bell Crank Lever Stop Spring	11-13-699	1	1
49	Governor Bell Crank Lever Adjusting Screw	26-98	1	1
50	Governor Bell Crank Lever Lock Nut	27-714	1	1
51	Governor Bell Crank Lever Spring	10-6-61	1	1
52	Governor Control Rod	11-13-697	1	1
53	Governor Shackle for Fuel Pump	11-13-696	1	1
54	Governor Shackle Fulcrum Pin	11-13-698	3	3
55	Governor Shackle Fulcrum Pin Split Pin	27-122	6	6


CAMSHAFT BEVEL GEAR AND GOVERNOR



Crankshaft and Piston Assembly

Item No.	Description	Part No.	Cylinders	
			2	3
	CRANKSHAFT	11-13-113c	1	-
	Balance Weight ...	10-5-62	2	-
	Balance Weight Dowel	27-800	2	-
1	CRANKSHAFT	12-13-760c	-	1
2	Balance Weight	12-5-81	-	6
3	Balance Weight Dowel	27-800	-	6
	Crankshaft Spigot Bush	11-13-109	1	1
4	Crankshaft Key for R.G. Sun Wheel	10-13-114	1	1
	Crankshaft Nut for R.G. Sun Wheel	X87/11022	1	1
5	Crankshaft Pinion	10-5-2	1	1
	Crankshaft Spur Gear	X87/16740	-	1
	Crankshaft Spur Gear	X87/11741	1	-
6	Crankshaft Pinion Key	27-785	1	1
CRANKSHAFT MAIN BEARINGS				
7	Main Bearing End Cover (Forward)	10-2-408	1	1
8	Main Bearing Gear End Inner	10-2-409	1	1
9	Main Bearing Gear End Outer (Aft)	10-2-410	1	1
10	Main Bearing Gear End Nut $\frac{3}{8}$ " Whit.	27-6	3	3
11	Main Bearing Gear End Felt Washer (in Spigot)	10-2-9	1	1
12	Main Bearing Gear End Joint	10-2-62A	1	1
13	Main Bearing Gear End Dowel	10-2-7	1	1
14	Centre Bearing (in Halves) 27-3 only	12-2-359	-	2
15	Centre Bearing Dowel	10-2-7	-	2
16	Intermediate Bearing Housing with Studs	12-5-15/16	-	1
	Intermediate Bearing Housing 2nd Bearing	12-5-17/18	-	1
	Intermediate Bearing Housing Screw	12-2-71	-	2
17	Intermediate Bearing Housing Stud	27-1075	-	4
18	Intermediate Bearing Housing Nut	27-26	-	4
19	Intermediate Bearing Housing Dowel	12-2-72	-	2
	Bearing Shim (used as required) .005 thick	10-2-12	-	
	CON ROD COMPLETE JK,	573-11630		
	" " " JP	573-10400.		
	CONNECTING ROD complete comprising:	10-4-25c	2	3
20	Connecting Rod with Cap	10-4-25	2	3
21	Connecting Rod Bush (Small End)	10-4-7	2	3
22	Connecting Rod Bearing (Large End) JP	010-04008 10-4-8	2	3
23	Connecting Rod Bolt	10-4-14	8	12
24	Connecting Rod Bolt Nut	27-796	8	12
25	Connecting Rod Bolt Split Pin	27-121	8	12
26	Connecting Rod Dowel	10-2-7	2	3
	CON ROD BEARING JK	010-04039		
	PISTON (complete)	010-04061 10-4-61c	2	3
27	Piston (Bare)	10-4-61	2	3
28	Piston Ring Taper	614-888	2	3
29	Piston Ring	10-4-18	4	6
30	Piston Scraper Ring Slotted	23-2299	2	3
	Piston Ring SET	574-10980		

CRANKSHAFT AND PISTON ASSEMBLY




J46

Crankshaft and Piston Assembly

Item No.	Description	Part No.	Cylinders	
			2	3
GUDGEON PIN				
31	Gudgeon Pin	10-4-3	2	3
32	Gudgeon Pin Spring Clip	28-99	4	6
CYLINDER LINER "LISTARD"				
33	Cylinder Liner	10-2-247	2	3
34	Cylinder Liner Rubber Ring	10-2-116	4	6
35	Cylinder Liner Adjusting Shim	10-2-12	As reqd.	
36	Balance Weight Stud	10-5-63	-	6
37	Balance Weight Nut	10-5-14	-	6

**ALWAYS QUOTE ENGINE
NUMBER
WHEN ORDERING SPARES**

CRANKSHAFT AND PISTON ASSEMBLY




J46

12V. Electric Starting Equipment

Item No.	Description	Part No.	Cylinders	
			2	3
1	Dynamo Type D5LA9 C.A.V. ...	12-8-346	1	1
2	Starter Motor Type BS512K/3 C.A.V. ...	12-8-360	1	1
3	Press Button Type 108/1 C.A.V. ...	12-8-364	1	1
4	Ammeter 30-0-30 Type A4138B ...	12-8-354	1	1
5	Control Box Type 107A/1 ...	12-8-351	1	1
6	Battery Type 3XC/15/1H C.A.V. 6 Volt ...	12-8-356	2	2
7	Control Panel ...	64-6212	1	1
	Cradle for Starter Motor Assembly Comprising :	24-5238	1	1
8	Cradle ...	24-5232	1	1
9	Cradle Cap ...	24-5233	1	1
10	Setcrew (Cradle to Cap) $\frac{3}{8}$ " B.S.F. ...	24-5253	4	4
11	Setcrew (Cradle to Bearer) $\frac{1}{2}$ " x $1\frac{1}{4}$ " B.S.F. ...	27-1504	4	4
12	Spring Washer $\frac{1}{2}$ " dia. ...	27-394	4	4
13	Flywheel ...	11-14-534	1	1
14	Starter Gear Ring ...	11-14-535	1	1
15	Dowel for Starter Bracket ...	210-410	2	2
	Cradle for Dynamo Assembly ...	24-5328	1	1
	Comprising :			
16	Cradle ...	24-5236	1	1
17	Cap ...	24-5237	1	1
18	Setcrew (Dynamo Cap to Cradle) $\frac{3}{8}$ " x $2\frac{5}{8}$ " B.S.F. ...	27-1686	4	4
19	Setcrew (Dynamo Cap to Starter Cap) $\frac{3}{8}$ " x $\frac{7}{8}$ " ...	27-974	4	4
20	Spring Washer for do. ...	27-393	4	4
21	Pulley 4" O/D ...	12-14-240	1	1
22	Woodruff Key No. 8 ...	27-2022	1	1
23	Pulley on Flywheel $10\frac{1}{4}$ " ...	11-13-727	1	1
24	Setcrew for Pulley $5/16$ " x $1\frac{1}{2}$ " B.S.F. ...	27-2093	4	4
25	$\frac{1}{4}$ " Whittle Belt x 60" ...		1	1
26	Engine Bearer (Port Side) ...	12-14-283	-	1
	Engine Bearer (Port Side) ...	11-14-283	1	-
27	Flywheel Guard for Starter and Dynamo ...	12-14-284	1	1
28	Support for Guard ...	24-5254	2	2
29	Nut for Support ...	27-905	2	2
30	Washer for Support ...	27-82	2	2
31	Bracket for Guard ...	24-5274	1	1
32	Set Screw for Guard $\frac{1}{2}$ " x $\frac{1}{2}$ " B.S.F. ...	27-899	2	2
33	Stud for Dynamo Stay ...	12-14-348	1	1
34	Nut for Dynamo Stay $\frac{1}{2}$ " Whit. ...	27-4	1	1
35	Stay for Dynamo ...	12-14-536	1	1
36	Anchor Block for Lub. Oil Pipe ...	12-14-353	1	1
37	Bolt for Block $5/16$ " x $2\frac{1}{8}$ " B.S.F. ...	27-1432	2	2
38	Connection ...	10-2-85	2	2
39	Oil Pipe (Engine to Bearer) ...	12-14-352	1	1

12-VOLT ELECTRIC STARTING EQUIPMENT




147

Flywheel and Hand Starting Gear

Item No.	Description	Part No.	Cylinders	
			2	3
1	Flywheel 23" Steel (Hand and Air Start only)	11-14-491	1	1
	Flywheel 23" C.I. (Elect. start)	11-14-534	1	1
2	Flywheel Key	27-1126	1	1
3	Flywheel Nut	10-5-39	1	1
4	Flywheel Locking Plate	10-5-40	1	1
5	Flywheel Locking Set Screw	10-5-41	3	3
6	Ratchet and Starting Sprocket (Bottom)	23-2216	1	1
7	Ratchet Pawl	23-2217	2	2
8	Ratchet Pawl Bush	23-2218	2	2
9	Ratchet Pawl Fulcrum Pin	23-697	2	2
10	Ratchet Cover	23-2220	1	1
11	Ratchet Cover Screws	10-5-41	4	4
12	Ratchet Pawl Springs	23-3826	2	2
13	Rivets for Ratchet Springs	27-3684	4	4
STARTING GEAR (Raised)				
14	Leaf Spring for Chain Adjuster	11-14-265	1	1
15	Support Tube for Leaf Spring	11-14-266	1	1
16	Locknut	27-689	2	2
17	Cap Nut	291-2128	1	1
18	Grease Nipple	27-2021	2	2
19	Starting Shaft Forward Bracket	10-13-99	1	1
20	Starting Shaft Aft Bracket	10-13-122	1	1
21	Starting Shaft	11-13-408	1	-
	Starting Shaft	12-13-408	-	1
22	Starting Shaft Pin for Handle	23-2224	2	2
23	Starting Shaft Pin for Handle	10-13-126	1	1
24	Woodruff Key	27-105	1	1
25	Shaft Collar	8-13-84	2	2
26	Taper Pin	27-811	3	3
27	Starting Handle complete	23-3156c	1	1
28	Chain with Fastener 146 Pitches	10-13-130	1	1
	Starting Shaft (when tachometer is fitted)	12-13-408	1	-
	Starting Shaft (when tachometer is fitted)	13-13-408	-	1
	Spare Link for Starting Chain	31-9148	-	-

**ALWAYS QUOTE ENGINE
NUMBER
WHEN ORDERING SPARES**

FLYWHEEL AND HAND STARTING GEAR



J49

Fuel Filters


Item No.	Description	Part No.	Cylinders	
			2	3
	FUEL FILTER, Single, complete, comprising the following parts	23-2283c	1	1
	Filter Body	23-2283	1	1
	Filter Cover	23-2282	1	1
	Filter Wick complete with connections	23-2288c	1	1
	Filter Wick Container	23-2279	1	1
	Filter Wick Container Clip	23-2280	2	2
	Filter Wick Nipple	23-2281	1	1
	Filter Wick Nipple Clip	23-2289	1	1
	Filter Vent Plug	10-2-89	1	1
	Filter Joint for Cover	23-2278	1	1
	Set Pin	27-888	4	4
	Filter Drain Plug	23-2291	1	1
	Filter Drain Plug Joint	103-91	1	1
	Filter Swivel Union	23-471	2	2
	Filter Swivel Union Screw	23-472	2	2
	Filter Swivel Union Joint	291-2265	4	4
	Filter Instruction Plate	27-1566	1	1
	Filter Instruction Plate Dowel	27-707	2	2
	Filter Set Screw	27-893	4	4
	FUEL FILTER—DUPLEX	10-2-321c	1	1
1	Filter Body	10-2-321	1	1
2	Filter Cover	10-2-322	2	2
3	Filter Cover Joint	10-2-328	2	2
4	Filter Cover Set Screw	27-888	10	10
5	Filter Cover Plug	10-2-336	2	2
6	Filter Cover Plug Joint	10-2-338	2	2
7	Filter Cover Plug	10-2-337	2	2
8	Filter Cover Plug Joint	10-2-339	2	2
9	Filter Vent Plug	10-2-89	2	2
10	Filter Wick, complete	23-2288c	2	2
11	Filter Nipple	23-2281	2	2
12	Filter Clip	23-2289	2	2
13	Filter Wick Container	23-2279	2	2
14	Filter Drain Plug	103-137	2	2
15	Filter Drain Plug Joint	103-91	2	2
16	Filter Valve Spindle	10-2-324	1	1
17	Filter Valve Spindle Hand Lever	10-2-325	1	1
18	Filter Gland	10-2-334	1	1
19	Filter Gland Cork Joint	10-2-335	1	1
20	Filter Gland Stud	27-1269	2	2
21	Filter Gland Nut	27-907	2	2
22	Filter Gland Spring Washer	27-1306	2	2
23	Filter Body Plug	10-2-336	3	3
24	Filter Body Plug Joint	10-2-338	3	3
25	Filter Body Plug	21-153	1	1
26	Filter Body Plug Joint	5197	1	1
27	Filter Swivel Union Screw	23-472	2	2
28	Filter Swivel Union Screw Joint	291-2265	4	4
29	Filter Instruction Plate (Cleaning)	27-1613	1	1
30	Filter Instruction Plate	27-2279	1	1
31	Filter Instruction Plate Dowels	27-707	6	6
32	Filter Outlet Swivel Union	23-471	1	1

[illegible]

Fuel Pump and Speed Control

Item No.	Description	Part No.	Cylinders	
			2	3
FUEL PUMP				
1	Fuel Pump complete	11-2-437	1	-
	Fuel Pump complete	12-2-437	-	1
2	Fuel Pump Coupling	10-2-414	1	1
3	Fuel Pump Coupling Fibre Disc	Y7021/129	1	1
4	Fuel Pump Tappet Assembly	7010/507	2	3
5	Fuel Pump Element	7009/44	2	3
6	Fuel Pump Helical Spring for Plunger	7010/9	2	3
7	Fuel Pump Delivery Valve and Seating	7010/188	2	3
8	Fuel Pump Delivery Valve Spring	7032/7	2	3
9	Fuel Pump Delivery Valve Holder	7010/479	2	3
10	Fuel Pump Pawl	11-13-701	1	1
11	Fuel Pump Pawl Check Pin	10-2-190	1	1
12	Fuel Pump Pawl Fulcrum Pin	11-13-703	1	1
13	Fuel Pump Pawl Check Plate	11-13-702	1	1
14	Fuel Pump Pawl Nut $\frac{3}{8}$ " BSF	27-1997	1	1
15	Fuel Pump Bracket (JP2M)	11-2-41	1	-
	Fuel Pump Bracket (JP3M)	12-2-41	-	1
	Fuel Pump Bracket (JK2M only)	11-2-453	1	-
	Fuel Pump Bracket (JK3M only)	12-2-453	-	1
16	Fuel Pump Bracket Nut $\frac{1}{2}$ " Whit.	27-4	2	2
17	Fuel Pump Bracket Shim	10-2-241	1	1
	Fuel Pump Set Pin	13-2-140	-	4
	Fuel Pump Set Pin	27-203	4	-
	Dowel for Bracket	10-2-110	-	2
	Spring Washer for Pump Bracket	27-393	-	4
	Plain Washer for Pump Bracket	27-184	4	-
SPEED CONTROL				
18	Speed Control Cover	11-13-373	1	1
19	Speed Control Handle	23-2932	1	1
20	Knob for Control Handle	31-967	1	1
21	Knurled Disc	23-2933	1	1
22	Screw (Disc to Handle)	27-3681	1	1
23	Screw (Cover to Bracket)	27-1524	2	2
24	Taper Pin (Handle and Lever to Spindle)	27-454	2	2
25	Detent Plug	23-679	2	2
26	Detent Spring	29-100 351-19510	2	2
27	Detent Grub Screw	27-3678	2	2
28	Spindle	11-13-370	1	1
29	Bottom End Lever	13-14-171	1	1
30	Swivel Pin	11-13-384	1	1
31	Swivel Pin Nut	27-1359	1	1
32	Swivel Pin Nut Split Pin	27-909	1	1
33	Adjusting Screw for Handle	27-3680	1	1
34	Adjusting Screw Locknut	27-905	1	1
	Speed Control Rod	12-14-173	-	1
35	Speed Control Rod	11-14-173	1	-
36	Speed Control Rod Adjusting Nuts	13-14-172	2	2
	Speed Control Rod Bracket	11-15-565	1	1
37	Locking Screw (Speed Cover)	23-2324	1	1
	Tommy Bar (Screw)	23-2325	1	1
38	Lock Nut	27-1453	2	2

FUEL PUMP AND SPEED CONTROL



Fuel Injector and Pipes

Item No.	Description	Part No.	Cylinders	
			2	3
FUEL INJECTOR (C.A.V.)				
	Fuel Injector complete	616-2144	2	3
	comprising :—			
1	Fuel Injector Nozzle Body and Valve	616-2145	2	3
2	Fuel Injector Flange	10-3-31	2	3
3	Fuel Injector Flange Nut $\frac{1}{8}$ " Whit.	27-5	4	6
4	Fuel Injector Copper Asbestos Joint	10-3-41	2	3
5	Fuel Injector Valve Spring	7008/7	2	3
FUEL PIPES AND DRIP CAN				
6	Fuel Pipe Tank to Filter	11-7-34	1	1
7	Fuel Pipe Filter to Pump	11-2-252	1	—
	Fuel Pipe Filter to Pump	12-2-252	—	1
8	Fuel Pipe Clip for 2 Pipes	26-218	1	—
	Fuel Pipe Clip for 3 Pipes	26-217	—	2
9	Fuel Pipe Clip Screws	27-483	2	4
	Fuel Pipe Injector to Non-Return Valve	11-3-183	1	—
	Non-Return Valve, complete	10-7-145	1	1
10	Fuel Pipe Injector to Non-Return Valve	12-3-183	—	1
	Fuel Pipe Pump to Injector	011-02473 11-2-499	1	—
	Fuel Pipe Pump to Injector	011-02475 11-2-450	1	—
11	Fuel Pipe Pump to Injector	12-2-449	—	1
12	Fuel Pipe Pump to Injector	12-2-450	—	1
13	Fuel Pipe Pump to Injector	12-2-451	—	1
	Fuel Pipe Clip Pad (JKM only)	11-3-248	1	1
	Fuel Pipe Clip Pad (JKM only)	12-3-248	—	2
	Fuel Pipe Clamping Plate (JKM only)	616-2277	—	1
	Fuel Pipe Clamping Plate (JKM only)	616-2279	1	1

This diagram illustrates the assembly of a fuel system component, likely a carburetor or fuel injector. The parts are numbered as follows:

- 1**: Main fuel body or carburetor housing.
- 2**: A small circular gasket or seal.
- 3**: A small bolt or screw.
- 4**: A small cylindrical component, possibly a filter or nozzle.
- 5**: A long, thin fuel line or hose.
- 6**: A small cylindrical component, possibly a filter or nozzle.
- 7**: A curved fuel line or hose with a flange.
- 8**: A small rectangular component, possibly a bracket or support.
- 9**: A small cylindrical component, possibly a filter or nozzle.
- 10**: A small cylindrical component, possibly a filter or nozzle.
- 11**: A small cylindrical component, possibly a filter or nozzle.
- 12**: A small cylindrical component, possibly a filter or nozzle.
- 13**: A small cylindrical component, possibly a filter or nozzle.


The diagram shows the assembly of these components into a fuel system. A dashed line indicates the assembly point for the fuel line (5) and the fuel body (1). The fuel line (5) is shown connected to the fuel body (1) and the fuel nozzle (4). The fuel line (7) is shown connected to the fuel body (1) and the fuel nozzle (4). The fuel line (11) is shown connected to the fuel body (1) and the fuel nozzle (4). The fuel line (12) is shown connected to the fuel body (1) and the fuel nozzle (4). The fuel line (13) is shown connected to the fuel body (1) and the fuel nozzle (4).

Heat Exchanger-JPM

Item No.	Description	Part No.	Cylinders	
			2	3
1	Cylinder	Z18112/8	1	-
	Cylinder	Z18112/12	-	1
2	Tube Stack	Z18103/8D	1	-
	Tube Stack	Z18103/12D	-	1
3	End Box (Fixed)	MZ7411	1	1
4	End Box (Expansion)	MZ7412	1	1
5	Leakage Ring	BZ3089/2	1	1
6	Joint Ring	BZ3097/4	4	4
7	Stud (Fixed End)	BZ3087/14	1	1
8	Stud (Expansion End)	BZ3087/15	1	1
9	Cap Nut	BZ3014B/2	2	2
10	Cap Nut Washer	BZ3013/3	2	2
11	Plug	BZ3247/2	5	5
12	Plug Joint	BZ3013/2	5	5
13	Loose Feet	MZ7364	2	2
14	Set Pin $\frac{1}{4}$ " Whit. x $\frac{1}{4}$ "		4	4
15	Shake Proof Washer $\frac{1}{4}$ "		4	4
16	Nameplate	BZ3141/A	1	1
17	Nameplate Drive Pin		4	4
18	Locating Stud	BZ3129/1	1	1
	Heat Exchanger complete	11-14-947	1	-
	Heat Exchanger complete	13-14-874	-	1
	Union	11-13-251	2	2
	Nuts	65-103	2	2
	Nipples	616-1708	2	2
	Flanges	616-1836	2	2
	Joints	616-1840	2	2
	Setscrews $\frac{1}{4}$ " x 1"	27-1329	4	4

**ALWAYS QUOTE SERIAL
NUMBER OF COOLER
WHEN ORDERING SPARES**

HEAT EXCHANGER-JPM




J52

Heat Exchanger-JKM

Item No.	Description	Part No.	Cylinders	
			2	3
	Heat Exchanger (complete)	292-3267	1	-
	Heat Exchanger (complete)	11-14-947	-	1
1	Cylinder	Z18104/4	1	-
	Cylinder	Z18112/8	-	1
2	Tube Stack	Z18103/4D	1	-
	Tube Stack	Z18103/8D	-	1
3	End Box (Fixed)	MZ7411	1	1
4	End Box (Expansion)	MZ7412	1	1
5	Leakage Ring	BZ3089/2	1	1
6	Joint Ring	BZ3097/4	4	4
7	Stud (Fixed End)	BZ3037/14	1	1
8	Stud (Expansion End)	BZ3087/15	1	1
9	Cap Nut	BZ3014B/2	2	2
10	Cap Nut Washer	BZ3013/3	2	2
11	Plug	BZ3247/2	5	5
12	Plug Joint	BZ3013/2	5	5
13	Loose Feet	MZ7364	2	2
16	Name Plate	BZ3141/A	1	1
17	Name Plate Drive Pin $\frac{1}{8}$ " x $\frac{1}{4}$ " Steel		4	4
18	Locating Stud	BZ3129/1	1	1

HEAT EXCHANGER-JKM




J52

Instruments and Panels

Item No.	Description	Part No.	Cylinders	
			2	3
1	Oil Pressure Gauge	616-1537	1	1
2	Screws	27-48	3	3
3	Instrument Panel (Small) complete, comprising :	13-14-439	1	1
	Instrument Panel	13-14-440	1	1
	Instrument Panel Support	616-1533	1	1
4	Water Temperature Gauge 3ft. Tube	616-1559	1	-
	Water Temperature Gauge 4ft. 6ins. Tube	616-1558	-	1
	Water Temperature Gauge 6ft. Tube	616-1536	To order	
	Water Temperature Gauge 12ft. Tube	616-1832	To order	
	Water Temperature Gauge 15ft. Tube	616-2043	To order	
5	Drive Bearing Housing	614-371		
6	Drive Bearing Housing	13-14-549	1	1
7	Drive Housing	13-14-144	1	1
8	Gitseal	27-2070	1	1
9	Tachometer Driving Sleeve	13-14-550	1	1
10	Driving Shaft (Short) JPM only	614-793	1	1
11	Driving Shaft Bush	614-397	2	2
12	Tachometer (Standard Rotation)	13-14-984	1	1
13	Tachometer Drive Cable	13-14-986	1	1
14	Instrument Panel (Large)	13-14-545	1	1
15	Screws $\frac{1}{4}$ " BSF x $\frac{3}{4}$ "	27-1195	2	2
16	Spring Washers	27-451	2	2
17	Instrument Panel Bracket	13-14-546	1	1
18	Studs $\frac{3}{8}$ " Whit. x $1\frac{1}{8}$ "	27-36	2	2
19	Setscrews $\frac{1}{4}$ " BSF x $\frac{3}{4}$ "	27-1195	2	2
20	Spring Washer $\frac{1}{4}$ "	27-451	2	2
21	Oil Pressure Gauge Adaptor	11-14-654	1	1
22	Drive Gear Wheel	614-792	1	1
23	Drive Gear Wheel Key	27-352	1	1
24	Drive Gear Lockwasher	614-674	1	1
25	Drive Gear Locknut	614-673	1	1
26	Joint	614-434	2	2
27	Housing Joint	13-14-166	As reqd.	
28	Adaptor Plate	13-15-475	1	1
	Drive Shaft (JKM only)	11-15-543	1	1
	Fixing Plug (JKM only)	201-15400	1	1
	Joint for Adaptor (JKM only)	11-15-501	2	2
	Housing Joint	13-14-166	As reqd.	

INSTRUMENTS AND PANELS




U53

Lubricating Oil Relief Valve, Pipes and Tank

Item No.	Description	Part No.	Cylinders	
			2	3
LUBRICATING OIL RELIEF VALVE				
1	Body	11-13-406	1	1
2	Plunger	11-13-439	1	1
3	Spring Seat	11-13-440	1	1
4	Adjusting Screw	11-13-292	1	1
5	Lock Nut	27-1996	1	1
6	Joint Washer	3306	1	1
7	Spring (Large)	11-13-957	1	1
8	Spring (Small)	11-13-441	1	1
9	Plug for Body	12407	1	1
10	Joint for Plug	12406	8	8
11	Pipe (Pressure Gauge to Crankcase)	11-13-970	1	-
	Pipe Pressure Gauge—Crankcase	12-13-970	-	1
12	Union Connection for $\frac{1}{4}$ " O.D. Pipe	10-2-85	8	8
	Washer for Union	10-6-64	8	8
13	Lub. Pipe—Scavenge to Relief Valve	12-13-955	1	1
14	Lub. Pipe—Pressure to Relief Valve	12-13-954	1	1
15	Lub. Pipe—Relief Valve to Engine	12-13-956	1	1
16	Lub. Pipe—to Water Pump (JPM only)	12-13-958	1	1
	Lub. Pipe—to Water Pump (JK2M only)	11-15-498	1	-
	Lub. Pipe—to Water Pump (JK3M only)	12-15-498	-	1
LUBRICATING OIL TANK				
17	Complete	390-184	1	1
18	Drain Plug	11-13-693	1	1
19	Drain Plug Joint	5197	1	1
20	Dipstick	390-197	1	1
21	Gauze Strainer with handle	23-3212	2	2
22	Spring Cup for Strainer	151-3	2	2
23	Cover Plate (Plain)	390-191	1	1
24	Cover Plate (with Filler)	390-200	1	1
25	Joint for Cover Plates	23-3207	1	1
26	Filler Cap	390-198	1	1
27	Joint for Filler Cap	303-253	1	1
28	Setscrew for Cover Plates	27-4074	16	16
29	Washer for Cover Plates	27-551	16	16
30	Pipe (Relief Valve to Tank and Tank to Pressure Pump)	616-1680	3	3
31	Breather Pipe	616-1674	1	1
32	Clamp Bracket for Oil Pipes	11-14-685	1	1
33	Setscrew for Bracket	27-201	1	1
34	Clamp	11-14-686	1	1
35	Clamp Setscrew	27-1991	1	1
36	Clamp Setscrew Spring Washer	27-451	1	1


LUBRICATING OIL RELIEF VALVE, PIPES AND TANK



Lubricating Oil Pump and Strainer

Item No.	Description	Part No.	Cylinders	
			2	3
	LUBRICATING OIL PUMP complete	11-13-280c	1	1
1	Scavenge Lubricating Pump Body	11-13-280	1	1
2	Supply Lubricating Pump Body	11-13-281	1	1
3	Driving Gear for Scavenge Pump	11-13-639	1	1
4	Driven Gear for Scavenge Pump	11-13-640	1	1
5	Driving Gear (Supply Pump)	10-2-158	1	1
6	Driven Gear (Supply Pump)	10-2-159	1	1
7	Woodruff Key for Driven Gears	27-566	2	2
8	Spindle Driving Gear	11-13-286	1	1
9	Spindle Driven Gears	11-13-285	1	1
10	Cover for Supply Pump	11-13-282	1	1
11	Cover Joint	10-2-113	2	2
12	Studs for Cover (Long)	11-13-297	1	1
13	Studs for Cover (Short)	11-13-298	1	1
14	Bolts for Cover (Long)	11-13-343	1	1
15	Bolts for Cover (Short)	11-13-344	1	1
16	Nuts for Studs	27-7	2	2
17	Set Screw (Pump to Crankcase)	27-1329	4	4
18	Bush for Supply Cover	11-13-287	1	1
19	Vertical Driving Shaft	11-13-288	1	1
20	Tube for Shaft	11-13-289	1	1
21	Loose Flange for Tube (Top)	10-2-94	1	1
22	Joint for Bottom Flange	10-2-115	1	1
23	Stud for Bottom Flange	27-1333	2	2
24	Nut for Bottom Flange	27-1334	2	2
25	Pump Casing Joints (to Crankcase)	10-2-112	1	1
26	Joint for Top Flange (Rubber)	10-3-38	1	1
27	Dowel for Pump Casing	10-2-110	2	1
28	LUBRICATING OIL STRAINER complete	11-13-882c	1	1
	Oil Strainer Gauze complete	10-2-107c	1	1
	Oil Strainer Flange	10-13-152	1	1
	Oil Strainer Suction Pipe	11-13-881	1	1
	Strainer Suction Pipe	23-1769	1	1
	Strainer Suction Pipe Nut	23-1768	1	1
29	Pipe Connection	10-13-151	1	1
30	Pipe Connection Joint	12406	1	1


LUBRICATING OIL PUMP AND PIPES



Centrifugal Circulating Pump

Item No.	Description	Part No.	Cylinders	
			2	3
	CIRCULATING PUMP complete	616-1720c	1	1
1	Pump Body	616-1720	1	1
2	Inlet Cover	616-790	1	1
3	Inlet Cover Joint	294-725	1	1
4	Setscrew $\frac{3}{8}$ " BSF x $\frac{3}{4}$ "	27-902	4	4
5	Spring Washer	27-393	4	4
6	Grease Nipple	27-920	1	1
7	Impeller	616-1722	1	1
8	Impeller Spindle	616-1757	1	1
9	Nut (Slotted Brass) $\frac{1}{2}$ "	23-619	1	1
10	Nut (Slotted) $\frac{1}{2}$ "	27-1305	1	1
11	Split Pin	27-3713	1	1
12	Split Pin	27-913	1	1
13	Key (Impeller)	27-107	1	1
14	Key (Pulley)	27-566	1	1
15	Oil Seal (Gaco)	291-2153	1	1
16	Carbon Ring	291-2150/1	1	1
17	Rubber Ring	291-2527/1	2	2
	Seal Washer	291-37910	1	1
18	Spring	291-2152/4	1	1
19	Spring Cage	291-2974	1	1
20	Bearing (Impeller End) M.S.8	11-13-321	1	1
21	Bearing (Pulley End)	27-1753	1	1
22	Packing Ring	11-19-850	1	1
23	End Plate	11-19-851	1	1
24	Felt Ring	10-2-34	1	1
25	Setscrew	27-1195	4	4
26	Drain Tap $\frac{1}{4}$ " BSP	5137	1	1
27	Joint	5197	3	3
28	Pulley (Driven)	11-14-584	1	1
29	Belting	11-2-458	1	1
30	Pump Drive Housing	13-14-144	1	1
	Pump Drive Housing (JKM only)	11-15-500	1	1
31	Pump Driving Housing Joint .005"	13-14-166	1	1
32	Pump Driving Housing Dowel	10-2-110	2	2
33	Pump Drive Gear Wheel	614-792	1	1
34	Pump Drive Gear Wheel Shaft	614-793	1	1
	Pump Drive Gear Wheel Shaft (JKM only)	11-15-531	1	1
35	Pump Drive Gear Wheel Shaft Key	27-352	1	1
36	Pump Drive Gear Wheel Lock Nut	614-673	1	1
37	Pump Drive Gear Wheel Washer	614-674	1	1
38	Bearing Housing (Blind)	614-370	1	1
39	Bearing Housing (Open)	614-371	1	1
	Bearing Housing (Open) (JKM only)	13-15-474	1	1
40	Bearing Housing Oil Seal	27-2070	1	1
41	Bearing Housing Joint .005"	11-15-561	2	2
42	Shaft Bush	614-397	2	2
43	Setscrews	27-1985	5	5
44	Blank Cover Plate	13-14-152	1	1
45	Blank Cover Plate Joint	13-14-153	1	1
46	Shim .030" (Drive Housing to C/case Door)	13-14-167	As reqd.	
	Shim .010" (Drive Housing to C/case Door)	13-14-168	As reqd.	
	Studs $\frac{1}{4}$ " Whit. x $2\frac{1}{2}$ "	27-217	3	3
47	Pulley (Driver)	11-14-583	1	1

FRESH WATER CENTRIFUGAL PUMP-JPM only




Centrifugal Circulating Pump-(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
48	Pulley Key 5/32" x 5/8" Woodruff	27-566	1	1
49	Setscrew 1/4" BSF x 2 1/32"	27-1285	1	1
50	Nut 1/4" BSF	27-907	1	1
51	Setscrew 1/4" Whit. x 9/16" (Drive Guard)	27-1711	2	2
	Spring Washer 1/4"	27-451	2	2
52	Setscrew 1/4" Whit. x 3" (Pump to Bracket)	27-1255	2	2
53	Washer 1/2"	614-811	1	1
54	Drain Extension	616-1593	1	1
55	Screw	2-508	1	1
56	Pump Bracket	11-14-563	1	1
57	Drive Guard } Not supplied	11-14-570	1	1
	Drive Guard Stay } separately	11-14-571	1	1
58	Pump Outlet Bend	11-14-568	1	1
59	Inlet Pipe to Silencer	11-14-580	1	1
60	Outlet Bend from Exhaust Manifold	13-14-464	1	1
61	Oval Joint	3309	6	6
62	Set Pins 5/16" BSF x 7/8"	27-1994	2	2
	Set Pins 5/16" Whit. x 7/8"	27-196	2	2
63	Bolts 5/8" Whit. x 1 1/4"	27-66	8	8
64	Nuts 5/8"	27-7	8	8
65	Washer 5/8"	27-413	12	12
	Union 3/8" x 1/4" BSP	616-968	1	1
66	Inlet Pipe to Crankcase	11-14-578	1	-
	Inlet Pipe to Crankcase	12-14-578	-	1
67	Outlet Manifold	13-13-886	1	-
	Outlet Manifold	12-13-470	-	1
68	Outlet Pipe	11-14-465	1	-
	W/C Manifold (Flanged Outlet)	11-13-202	1	-
	W/C Manifold (Flanged Outlet)	12-13-202	-	1
	Water Inlet Restrictor	11-3-294	6	6
	Pipe and Ferrule Assembly	11-3-299	2	2

**ALWAYS QUOTE ENGINE
NUMBER
WHEN ORDERING SPARES**


FRESH WATER CENTRIFUGAL PUMP-JPM only



Sea Water Pump

Item No.	Description	Part No.	Cylinders	
			2	3
	Raw Water Pump complete	11-15-571	1	1
1	Adaptor Plate	11-15-539	1	1
2	Adaptor Plate Joint	11-15-501	1	1
3	Setscrew	270-24	2	2
4	Spring Washer	27-413	1	1
*5	Driving Gear Housing	291-2501/1	1	1
6	Housing Joint	291-2502	1	1
7	Setscrew	270-25	3	3
8	Spring Washer	27-1976	3	3
*9	Plug for Oil Hole	211-540	1	1
*10	Plug Joint	600-106	1	1
*11	Locating Bearing	291-2980	2	2
*12	Locating Bearing Pin	291-2987	2	2
*13	Driving Gear Shaft Assembly	291-3095/2	1	1
*14	Driven Gear Shaft Assembly	291-3096/2	1	1
*15	Thrust Washer	291-2983	2	2
*16	Circlip	291-2988	2	2
17	Driving Gear	614-792	1	1
*18	Cap Screw	27-4414	1	1
*19	Dowel	291-2522	2	2
*20	Reduction Pinion	11-15-530	1	1
*21	Pinion Bush	291-2511	1	1
*22	Reduction Gear	11-15-529	1	1
*23	Setscrew	270-195	3	3
*24	Dowel	291-2522	2	2
*25	Cheese Head Set Screw	27-4386	3	3
*26	Gear Shaft Oil Seal	291-2153	4	4
*27	Seal Ring	291-21502	4	4
*28	Rubber Ring	291-2527/1	8	8
*29	Seal Spring	291-2152/4	4	4
*30	Cage for Carbon Seal	291-39600	4	4
*30a	Thrust Washer	291-38860	4	4
*31	Snap Ring	291-39570	4	4
	Rubber Ring	520-7577	1	1
*32	Pump Body	291-2517/1	1	1
*33	Dividing Plate	291-2515/1	2	2
*34	Joint	291-2516/1	6	6
*35	Impeller complete	291-2487/5	2	2
*36	Bearing Housing	291-2514/1	1	1
*37	Bearing Bush	291-2512/1	2	2
*38	Bearing Block	291-2540/1	2	2
*39	Driving Pin	291-2976	2	2
*40	Circlip for Driving Pin	291-2037	2	2
*41	Rubber Sealing Ring	291-2989	2	2
*42	Cover for Bearing Housing	291-2513/1	1	1
*43	Cover Joint	291-2885/1	1	1
*44	Filling and Level Oil Plugs	211-540	2	2
*45	Plug Joint	600-106	2	2
*46	Locating Pin	291-3099	2	2
*47	Locating Nuts	270-14	6	6
*48	Through Bolts	291-2519/1	4	4
*49	Through Bolts Nuts	270-14	4	4
50	Delivery Bend	291-3153	1	1
51	Suction Elbow	11-15-547	1	1


SEA WATER PUMP



Sea Water Pump—(Contd.)

Item No.	Description	Part No.	Cylinders	
			2	3
52	Joint	23-1766	2	2
53	Setscrew (Suction)	270-26	2	2
54	Delivery Elbow Setscrew	270-28	1	1
55	Delivery Elbow Setscrew	270-25	1	1
56	Plug for Bend and Elbow	21-153	2	2
57	Spring Washer	27-1976	8	8
61	Lub. Oil Feed Pipe	11-15-498	1	-
	Lub. Oil Feed Pipe	12-15-498	-	1
	Lub. Oil Feed Pipe Union	103-106	-	1
	Swivel Union Plug	23-4315	1	-
*62	Fixing Plug	842-359	1	1
64	Joints	600-106	2	2
*65	Felt Lubricating Strip	291-2521	2	2
*66	Felt Lubricating Plug	291-2520	4	4
67	Safety Valve complete	291-2990	1	1
	comprising :—Body	291-2991	1	1
	Plunger	291-2992	1	1
	Rubber Washer	291-2993	1	1
	Spring	291-3061	1	1
	Plug	11-13-198	1	1
	Joint	13-21-778	1	1
	Water Drain Plug	291-40790	2	2
*68	Water Drain Plug	291-2609	2	2
*69	Water Drain Plug Joint	13-21-778	1	1
70	Safety Valve Joint			


SEA WATER PUMP



Sea Water & Bilge Pump

Item No.	Description	Part No.	Cylinders	
			2	3
	Sea Water and Bilge Pump complete	11-15-572	1	1
1	Adaptor Plate	11-15-539	1	1
2	Adaptor Plate Joint	11-15-501	1	1
3	Setscrew	270-24	2	2
4	Spring Washer	27-413	2	2
*5	Driving Gear Housing	291-2501/1	1	1
6	Housing Joint	291-2502	1	1
7	Setscrew	270-25	3	3
8	Spring Washer	27-1976	3	3
*9	Plug for Oil Hole	211-540	1	1
*10	Plug Joint	600-106	1	1
*11	Locating Bearing	291-2980	2	2
*12	Locating Bearing Pin	291-2987	2	2
*13	Driving Gear Shaft Assembly	291-2507/4	1	1
*14	Driven Gear Shaft Assembly	291-2510/4	1	1
*15	Thrust Washer	291-2983	2	2
*16	Circlip	291-2988	2	2
17	Driving Gear	614-792	1	1
*18	Cap Screw	27-4414	1	1
*19	Dowel	291-2522	1	1
*20	Reduction Pinion	11-15-530	1	1
*21	Pinion Bush	291-2511	1	1
*22	Reduction Gear	11-15-529	1	1
*23	Cap Head Setscrew	270-195	3	3
*24	Dowel	291-2522	2	2
*25	Cheesehead Screw	27-4386	1	1
*26	Gear Shaft Oil Seal	291-2153	4	4
*27	Seal Ring	291-21502	4	4
*28	Rubber Ring	291-2527/1	20	20
*29	Seal Spring	291-2152/4	4	4
*30	Cage for Carbon	291-39600	4	4
*30a	Thrust Washer	291-38860	4	4
*31	Snap Ring	291-39570	4	4
	Rubber Ring	520-7577	4	4
*32	Pump Body	291-2517/1	2	2
*33	Dividing Plate	291-2515/1	3	3
*34	Joint	291-2516/1	6	6
*35	Impeller complete	291-2487/5	4	4
*36	Bearing Housing	291-2514/1	1	1
*37	Bearing Bush	291-2512/1	2	2
*38	Bearing Block	291-2540/1	2	2
*39	Driving Pin	291-2976	2	2
*40	Circlip for Driving Pin	291-2037	2	2
*41	Rubber Sealing Ring	291-2989	2	2
*42	Cover for Bearing Housing	291-2513/1	1	1
*43	Cover Joint	291-2885/1	1	1
*44	Filling and Level Oil Plugs	211-540	2	2
*45	Plug Joint	600-106	2	2
*46	Locating Pin	291-2518/1	2	2
*47	Locating Nuts	270-14	6	6
*48	Through Bolts	291-2519/1	4	4
*49	Through Bolts Nuts	270-14	4	4
50	Delivery Elbow	292-3153	2	2
	Delivery Bend (Reverse Rotation)	291-3153	2	2


SEA WATER & BILGE PUMP



Sea Water & Bilge Pump—(Contd.)

Item No.	Description	Part No.	Cylinders	
			2	3
51	Suction Elbow (Bilge)	11-15-499	1	1
	Suction Elbow	11-15-547	1	1
	Joint (Suction)	23-1766	1	1
52	Joint (Delivery)	23-1766	—	—
52a	Joint	13-22-350	2	2
53	Setscrew (Suction)	270-26	2	2
54	Delivery Bend Setscrew	270-28	2	2
55	Delivery Elbow Setscrew	270-26	1	1
56	Plug for Bend and Elbow	21-153	2	2
57	Spring Washer	27-413	8	8
58	Wetting Pipe for Bilge Pump	11-15-503	1	1
59	Union	291-3320	2	2
60	Joint for Wetting Union Pipe	13-22-350	2	2
61	Lub. Oil Feed Pipe	11-15-498	1	—
	Lub. Oil Feed Pipe	12-15-498	—	1
	Lub. Oil Feed Pipe Union	103-106	—	1
*62	Fixing Plug	842-359	1	1
64	Joints	600-106	2	2
*65	Felt Lubricating Strip	291-2521	2	2
*66	Felt Lubricating Plug	291-2520	4	4
67	Safety Valve complete	291-2990	2	2
	comprising :—Body	291-2991	2	2
	Plunger	291-2992	2	2
	Rubber Washer	291-2993	2	2
	Spring	291-3061	2	2
	Plug	11-13-198	2	2
	Joint	13-21-778	2	2
*68	Water Drain Plug	291-40790	4	4
*69	Water Drain Plug Joint	291-2609	4	4
70	Safety Valve Joint	13-21-778	2	2


SEA WATER & BILGE PUMP



Reverse Gear

Item No.	Description	Part No.	Cylinders	
			2	3
	Casing Top and Bottom Halves (complete)	11-13-856	1	1
1	Casing Bottom Half R.H.	11-13-854	1	1
	Casing Bottom Half L.H.	11-13-857	1	1
2	Casing Top Half	11-13-855	1	1
3	Casing Top to Bottom Joint	614-558	1	1
4	Casing to Engine Joint	614-557	1	1
5	Casing Inspection Cover	23-3259	1	1
6	Inspection Cover Joint	23-3453	1	1
7	Setscrew $\frac{7}{16}$ " B.S. Whit.	27-1338	8	8
8	Setscrew $\frac{3}{4}$ " B.S. Whit.	27-203	6	6
9	Crankshaft Spur Gear	X87/11741	1	—
	Crankshaft Spur Gear	X87/16740	—	1
10	Crankshaft Nut	X87/11022	1	1
11	Crankshaft Bush	X87/11910	1	1
12	Clutch Shaft	X87/11047	1	1
13	Reverse Shaft Spur Gear Key	X99/3288	1	1
14	Sliding Sleeve Key	X99/2327	1	1
15	Countersunk Head Screw $\frac{1}{4}$ " BSF	X99/8997	1	1
16	Half Coupling or Pinion Key	X99/3856	1	1
17	Joint Ring	12-15-483	1	1
18	Joint	X87/11820	1	1
19	Ball Bearing Housing	12-15-482	1	1
20	Bolt— $\frac{1}{2}$ " Whit.	27-426	3	3
21	Spring Washer	13-22-350	3	3
22	Nut— $\frac{1}{2}$ " Whit.	27-4	3	3
23	Ball Bearing (Direct Drive only)	X99/3989	1	1
24	Locating Ring Nut	X87/11300	1	1
25	Allen Setscrew $\frac{1}{4}$ " BSF	X99/5203	1	1
26	Weston Seal	X99/2331	1	1
27	Half Coupling (Direct Drive only)	X87/11101	1	1
28	Pinion Retaining Nut Washer	X87/11200	1	1
29	Pinion or Coupling Retaining Nut	X87/11980	1	1
30	Split Pin	X99/2673	1	1
31	Tail Shaft Half Coupling (Direct Drive only)	X87/11861	1	1
32	Coupling Bolt (Direct Drive only)	X87/19330	4	4
33	Coupling Bolt Nut	X99/5358	4	4
34	Clutch Body Bush (large)	X87/11110	1	1
35	Clutch Shaft Nut	X87/11063	1	1
36	Countersunk Head Screw— $\frac{5}{16}$ " BSF	X99/2640	3	3
37	Clutch Shaft Spur Gear	X87/11053	1	1
38	Clutch Spider Spur Gear Key (Inner)	X99/3289	1	1
39	Clutch Body	294-40300	1	1
40	Spur Pinion Shaft Locking Screw	X87/14521	4	4
41	Clutch Body Key	X87/11120	2	2
42	Clutch Body Key Socket Head Screw $\frac{1}{4}$ " BSF	X99/8996	4	4
43	Spur Pinion Stepped	X87/11141	2	2
44	Spur Pinion Bush	X87/11710	4	4
45	Spur Pinion Shaft	X87/11161	4	4
46	Spur Pinion Shaft Oil Hole Plug	X87/11181	4	4
47	Spur Pinion	X87/11131	2	2
48	Clutch Body Bush (small)	X87/11090	1	1
49	Clutch Body Bush Joint Screw— $\frac{3}{16}$ " B.S.F.	X99/4131	1	1
50	Clutch Spider	294-40340	1	1
51	Clutch Spider Key	X87/11210	2	2


REVERSE GEAR



Reverse Gear-(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
52	Clutch Spider Key Socket Head Screw	X99/8996	2	2
53	Clutch Plate (large)	294-40320	3	3
54	Clutch Plate (small)	294-40310	2	2
55	Clutch Gripping Plate	294-40330	1	1
56	Toggle Lever Plate	X87/11250	1	1
57	Toggle Lever Plate Nut Locking Plate	X87/11270	1	1
58	Toggle Lever Plate Nut	X87/11260	1	1
59	Toggle Lever	X87/11291	2	2
60	Sliding Sleeve	X87/11341	1	1
61	Toggle Lever Screw	X87/11311	2	2
62	Toggle Lever Screw Washer	X99/2577	2	2
63	Locknut—7/16" B.S.F.	X99/2467	2	2
64	Sliding Sleeve Link Pin	X87/11332	2	2
65	Sliding Sleeve Link	X87/11322	4	4
66	Toggle Lever Link Pin	294-3029	2	2
67	Toggle Lever Fulcrum Pin	X87/11282	2	2
68	Split Pin	X99/2454	14	14
69	Link Pin Washer	X99/1704	10	10
70	Sliding Sleeve Fork Lever Die	X87/11371	1	1
71	Sliding Sleeve Fork Lever	X87/11383	1	1
72	Sliding Sleeve Die Screw	X87/11362	2	2
73	Spring Washer	X99/2577	2	2
74	Brake Band Lining Assembly, complete	294-40240	1	1
	Brake Band	294-39811	1	1
	Brake Band Lining	294-39820	3	3
	Brake Band Lining Rivet	294-40250	21	21
75	Brake Band Position Screw	X87/11831	1	1
76	Brake Band Position Stud	27-769	1	1
	Brake Band Position Spring Washer	27-984	1	1
	Brake Band Position Nut—7/16" Whit.	27-4	1	1
77	Brake Band Position Sleeve	294-39850	1	1
78	Brake Band Spring	2-1864	1	1
79	Brake Band Spring Cap	294-39860	1	1
80	Brake Band Lever Bracket (Standard rotation)	X87/11733	1	1
	Brake Band Lever Bracket (Rev. rotation)	X87/11721	1	1
81	Brake Band Lever Bracket Set Screw—1/4" Whit.	27-426	2	2
82	Brake Band Lever Bracket Spring Washer	27-394	2	2
83	Brake Band Lever (Standard rotation)	294-39870	1	1
	Brake Band Lever (Reverse rotation)	294-39880	1	1
84	Brake Band Lever Fulcrum Pin	X87/11521	1	1
85	Brake Band Lever Fulcrum Pin Washer	X99/2577	1	1
86	Brake Band Lever Fulcrum Pin Locknut	X99/2470	1	1
87	Locking Plunger Spring	X87/11760	1	1
88	Lever Bracket Plunger	X87/11750	1	1
89	Lever Adjusting Screw	X87/11512	1	1
90	Lever Adjusting Screw Locknut—1/4" B.S.F.	X99/2468	1	1
91	Reverse Lever Socket	X87/11663	1	1
92	Reverse Lever	X87/11572	1	1
93	Reverse Lever Locating Plunger Pin	X87/14680	1	1
94	Reverse Lever Grip	X87/11672	1	1
95	Reverse Lever Setscrew—1/4" B.S.F.	X99/3645	1	1
96	Reverse Lever Locating Plunger	X87/14670	1	1
97	Reverse Lever Locating Plunger Spring	X99/5871	1	1
98	Reverse Lever Locating Plunger Guide	X87/11970	1	1

REVERSE GEAR




Reverse Gear-(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
99	Reverse Lever Locating Plate	24-5130	1	1
	Reverse Lever Locating Plate Dowel Pin	10-2-110	1	1
100	Locating Plate Setscrew, Locking Plate	24-5131	1	1
101	Locking Plate Setscrew— $\frac{3}{8}$ " Whit.	27-203	2	2
102	Reverse Lever Setscrew— $\frac{3}{8}$ " B.S.F.	X99/3815	1	1
103	Reverse Lever Key	X87/11790	1	1
104	Fork Lever Cross Shafts	X87/11392	1	1
105	Felt Washer	27-1094	1	1
106	Felt Washer Retaining Plate	296-515	1	1
107	Felt Washer Retaining Plate Setscrew— $\frac{5}{16}$ " Whit.	27-150	4	4
108	Cross Shaft Collar	X87/11411	1	1
109	Cross Shaft Collar Spring Washer	X99/2573	1	1
110	Cross Shaft Collar Setscrew— $\frac{7}{16}$ " Whit.	27-1338	1	1
111	Brake Band Roller Lever (Standard rotation)	X87/11431	1	1
	Brake Band Roller Lever (Rev. rotation)	X87/11441	1	1
112	Lever Cross Shaft	X87/11442	1	1
113	Brake Band Lever Roller	X87/11460	1	1
114	Lever Roller Pin	X87/11472	1	1
115	Split Pin	X99/2454	12	12
116	Cross Shaft Locating Screw	X87/11451	2	2
117	Spring Washer	X99/2573	1	1
118	Reverse Lever Stop	11-13-792	1	1
119	Reverse Lever Stop Setscrew	27-1883	2	2
	Locking Wire 16 S.W.G. x 5" long	X99/5866	4	4
	No. 6 Drive Pins	X99/1612	2	2
	Reverse Gear Number Plate	X87/11890	1	1
	Warning Plate	27-3943	1	1
	Warning Plate Screws	64/7175/1	2	2
121	Adjusting Screw for Reverse Lever Stop	X87/11512	1	1
122	Adjusting Screw Lock Nut	X99/2468	1	1

SPECIAL TOOLS

Clutch Shaft Nut Spanner	X87/11920	1	1
Crankshaft Nut Spanner	X87/11940	1	1
Spanner Tommy Bar	X87/11930	1	1


REVERSE GEAR



2:1 Reduction Gear

Item No.	Description	Part No.	Cylinders	
			2	3
1	Gear Casing	X87/17011	1	1
2	Gear Casing Cover	X87/17020	1	1
3	Reversing Shaft End Cover	X87/17050	1	1
4	Secondary Shaft End Cover	X87/17170	1	1
5	Cover for Water Jacket	X87/10190	2	2
6	Tail Shaft Half Coupling	X87/11870	1	1
7	20 Teeth Pinion } only supplied	294-38480	1	1
8	41 Teeth Gear } together	294-38490	1	1
9	Secondary Shaft	X87/17120	1	1
10	Key	X99/3884	1	1
11	Dipstick Knob	X87/10260	1	1
12	Oil Drain Plug	X87/10180	1	1
13	Cap Nut $\frac{1}{4}$ " B.S.F.	X99/2195	9	9
14	Cap Nut $\frac{5}{16}$ " B.S.F.	X99/2194	8	8
15	Water Drain Plug	X99/5844	2	2
	Water Pipe—Reduction Gear to Pump	11-15-554	1	1
16	Flange	X87/10280	1	1
	Nut	65-103	1	1
	Nipple	11-13-252	1	1
	Water Pipe—Inlet to Reduction Gear—1.112" O.D. x 6'			
	Copper Pipe	11-13-947	1	1
17	Breather Pipe	X87/10320	1	1
18	Breather Pipe Socket	X99/1376	1	1
19	Breather Pipe Plug	X99/5843	1	1
20	Dipstick	X87/10210	1	1
21	Distance Piece	X87/10270	2	2
22	Secondary Shaft Nut	X87/10141	1	1
23	Coupling Bolt	X87/11880	6	6
24	Gear Casing Cover Stud	X99/1802	3	3
25	Secondary Shaft End Cover Stud	X99/1752	6	6
26	Water Flange Stud	X99/1850	4	4
27	Water Jacket Cover Stud	X99/1884	4	4
28	End Cover Setscrew	X99/3224	4	4
29	Coupling Bolt Nut	X99/5358	6	6
30	Split Pin	X99/2663	1	1
31	Dowel Pin $\frac{3}{8}$ "	X99/3567	2	2
	Drive Pin	X99/1612	2	2
33	Reduction Gear Number Plate	X87/10310	1	1
34	Breathing Pipe Plug Joint	X99/5845	1	1
35	Water Drain Plug Joint	X99/5846	2	2
36	Oil Drain Plug Joint	X99/2210	1	1
37	Water Flange Joint	X87/10290	2	2
38	Water Jacket Cover Joint	X99/2214	2	2
39	End Cover Joint	X99/2215	1	1
41	Weston Seal	X99/1749	2	2
42	Roller Bearing $1\frac{1}{2}$ " x $3\frac{1}{4}$ " x $\frac{3}{4}$ "	X99/3985	1	1
43	Ball Bearing $1\frac{1}{2}$ " x $3\frac{1}{4}$ " x $\frac{15}{16}$ "	X99/4027	1	1
44	Ball Bearing 45 mm. x 100 mm. x 25 mm.	X99/2677	1	1
45	Double Purpose Bearing $2\frac{1}{4}$ " x 5" x $1\frac{1}{4}$ "	X99/3984	1	1
46	Stud $\frac{1}{2}$ " Whit. x $6\frac{1}{2}$ "	27-1950	4	4
47	Nut $\frac{1}{2}$ " Whit.	27-4	2	2
48	Cap Nut $\frac{1}{2}$ " Whit.	27-567	2	2
	Spring Washer	27-394	2	2
51	Packing Shim	G/4828	2	2

2:1 REDUCTION GEAR



3:1 Reduction Gear

Description	Part No.	Cylinders	
		2	3
Gear Case	294-3748	1	1
Gear Case End Cover	294-3749	1	1
Gear Case Assembly: comprising above	294-3747	1	1
Paper Joint	X87/11820	2	2
Pinion	294-3756	1	1
Roller Bearing $1\frac{1}{2}$ " x $3\frac{3}{4}$ " x $15/16$ "	294-3758	1	1
Ball Bearing $1\frac{1}{2}$ " x $3\frac{3}{4}$ " x $15/16$ "	X99/4027	1	1
Paper Joint	294-3759	1	1
Bearing Housing Cap	294-3760	1	1
Roller Bearing 2" x $4\frac{1}{2}$ " x $4\frac{1}{16}$ "	294-3763	1	1
Secondary Shaft	294-3750	1	1
Seeger Circlip ($4\frac{1}{2}$ ")	294-3764	1	1
Gear Wheel	294-3754	1	1
Gear Wheel Key	X99/3884	1	1
Secondary Shaft Nut	294-3766	1	1
Thrust Bearing 60 mm. x 150 mm. x 35 mm.	X99/4113	1	1
Oil Seal	X99/4129	2	2
Secondary Shaft end cover	294-3753	1	1
Oil Drain Plug	X87/10180	1	1
Oil Drain Plug Joint	291-3063	1	1
Water Drain Plug	X99/5844	2	2
Water Drain Plug Joint	13-22-350	2	2
Water Jacket Cover	X87/10190	2	2
Joint	X99/2214	2	2
Dipstick	294-3762	1	1
Dipstick Knob	X87/10260	1	1
Stud (Gear Case to Rev. Gear)	27-4449	2	2
Stud (Gear Casing)	X99/2042	5	5
Stud (Secondary Shaft End Cover)	X99/1752	6	6
Setscrew for bearing cap	X99/3224	4	4
Stud for water flange	X99/1850	4	4
Cap Nut $\frac{1}{2}$ " B.S.F.	X99/2195	11	11
Cap Nut $5/16$ " B.S.F.	X99/2194	8	8
Joint Ring	12-15-483	1	1
Dowel Pin	291-2586	2	2
Water Flange	X87/10280	2	2
Water Flange Joint	X87/10290	2	2
Stud (for Water Jacket Cover) $5/16$ "	X99/1884	4	4
Number Plate	X87/10310	1	1
Breather Pipe	X87/10320	1	1
Breather Pipe Socket	X99/1376	1	1
Breather Pipe Plug	X99/5843	1	1
Breather Pipe Plug Joint	13-21-778	1	1
Packing Shim	G4828	2	2
Number Plate Drive Pin	X99/1612	2	2
Half Coupling	X87/19340	1	1
Half Coupling Bolt	X87/19330	6	6
Half Coupling Nut	X99/5358	6	6
Split Pin Secondary Shaft Nut $\frac{1}{2}$ "	27-4040	1	1
Stud $\frac{1}{2}$ " Whit. x $6\frac{1}{2}$ "	27-1950	2	2
Cap Nut	27-567	2	2
Plain Nut	27-4	2	2
Spring Washer	27-394	2	2
Cap Nut $\frac{1}{2}$ " B.S.F.	X99/2197	2	2
Water Pipe—Red. Gear to Pump	12-13-946	1	1
Water Pipe—Inlet to Red. Gear	11-13-947	1	1

Temperature Control Valve (Diaphragm Type)

Description	Part No.	Cylinders	
		2	3
Temperature Control Valve Complete Assy.	571-10180	1	1
Valve Cover	291-40560	1	1
Valve Body	291-40570	1	1
Valve Cover Screws	270-463	6	6
Valve Cover Washers	616-1601	6	6
Valve Diaphragm	291-40580	3	3
Valve Diaphragm Clamping Plate	291-40650	1	1
Valve Diaphragm Clamping Plate Nut	270-14	1	1
Valve Stem	291-40590	1	1
Valve Lifting Knob	291-40600	1	1
Valve Plate	291-3483	1	1
Valve Spindle	291-40610	1	1
Valve Plate Screws	64-3552/5	2	2
Valve Spindle Packing	520-7517	1	1
Valve Spindle Gland Nut	520-7605	1	1
Washer for Clamping Plate	64-6618/8	1	1
Valve Spring	291-40620	1	1
Valve Control Door	291-3497	1	1
Valve Control Door Pin	201-11730	1	1
Valve Control Door Pin Stop	291-3484	1	1
Valve Indicator Plate	291-40710	1	1
Valve Indicator Plate Dowels	27-707	2	2
Packing Washer	291-40630	As req.	
$\frac{1}{4}$ " BSP Plug } for Engines without Joint } W. C. Manifold			


Temperature Control Valve—JKM Plunger Type

Temperature Control Valve comp.	571-10040	1	1
Body	291-38380	1	1
Plunger	291-38390	1	1
Spring	291-38400	1	1
Cover	291-38410	1	1
Cover Joint	291-38430	1	1
Cover Screws	270-103	3	3
Spring Washer	27-717	3	3
Valve Plate	291-3483	1	1
Spindle	291-3482	1	1
Packing	520-7517	1	1
Gland Nut	520-7605	1	1
Control Lever	291-3497	1	1
Lever Pin	201-11730	1	1
Lever Stop	291-3484	1	1
Indicator Plate	291-3485	1	1
Dowel	27-707	2	2
Plug	11-13-198	1	1
Plug Joint	12406	1	1
Plate Screws	64-3552/5	2	2
Instruction Plate	291-38420	1	1

Fresh Water and Fuel Tanks

Item No.	Description	Part No.	Cylinders	
			2	3
1	Fresh Water Balance Tank	616-1520	1	1
2	Overflow and Vent Connection	616-1522	1	1
3	Drain Plug	211-540	1	1
4	Strap	23-4979	2	2
5	Bracket	23-2154	2	2
6	Hook Bolt	8-7-103	2	2
7	Wing Nut	27-907	2	2
8	1 in. Gate Valve	12-14-223	1	1
9	Marine Fuel Tank (10 gallons)	11-13-787	1	1
10	Dipstick	23-3198	1	1
11	Filling Strainer	11-13-888	1	1
12	Filler Plug	10-13-132	1	1
13	Vent Pipe	11-13-948	1	1
14	Fuel Supply Valve	10-7-50	1	1
15	Joint	12406	1	1
16	Drain Plug	12-21-917	1	1
17	Joint	12406	1	1
18	Union	12427	1	1
19	Reducing Plug	3128	1	1


FRESH WATER AND FUEL TANKS



Silencers

Item No.	Description	Part No.	Cylinders	
			2	3
	Engine Exhaust Silencer complete, comprising	11-13-895c	1	1
1	Exhaust Silencer Body	11-13-895	1	1
2	Exhaust Silencer Outlet Cover	11-13-148	1	1
3	Exhaust Silencer S/Control Cover	11-13-369	1	1
4	Expansion Plug for Silencer	27-801	8	8
5	Stud (End Cover to Silencer)	27-45	12	12
6	Dome Nut Cover to Silencer	27-1974	12	12
7	Stud Starting Bracket to Silencer	27-1362	2	2
8	Silencer Exhaust Pipe Flange	10-13-158	1	1
9	Screw for ditto	27-647	4	4
10	Silencer Ex. Flange Joint	11-13-422	1	1
11	Plug for Vent Tap	11-13-452	1	1
12	Silencer Vent Tap	5137	1	1
13	Screw (Silencer to Ex. Manifold)	27-68	2	2
14	Screw (Silencer to Ex. Manifold)	27-38	2	2
15	Nut (Starting Bracket to Silencer)	27-6	2	2
16	Joint (Silencer to Crankcase)	11-13-901	1	1
17	Joint (Silencer to Manifold)	11-13-206	1	1
18	Stud (Silencer to Crankcase)	27-1519	2	2
19	Water Outlet Pipe to Crankcase	11-13-900c	1	-
	Comprising :—			
	Water Outlet Elbow	11-13-897	1	-
	Water Outlet Pipe	11-13-898	1	-
	Water Inlet Elbow	11-13-899	1	-
	Water Outlet Pipe to Crankcase	12-13-900c	-	1
	Comprising :—			
	Water Outlet Elbow	11-13-897	-	1
	Water Outlet Pipe	11-13-898	-	1
	Water Inlet Elbow	11-13-899	-	1
20	Joint for Outlet Elbow	27-2068	1	1
21	Screws for Outlet Elbow	27-203	2	2
22	Secondary Dry Silencer	11-21-561	1	1
23	Secondary W/C Silencer	11-21-562	1	1

SILENCERS




J60

Dynamo-JPM & JKM

Item No.	Description	Part No.	Cylinders	
			2	3
1	Screw securing Pole Piece	5333A-99A	8	8
2	Pole Piece Insulator	5603-62	8	8
3	Field Coil Assembly	F.86	Set	
4	Positive Brush Connector	5603-202	1	1
5	Negative Brush Connector	5603-202A	1	1
6	Terminal, R.C.	5459-189	2	2
7	Dowel Pin for Yoke	5314-76	1	1
8	Locating Pin	5265-11	2	2
	Commutator End Shield, Assembled with Brushgear	5603-117H	1	1
9	Commutator End Shield	5603A-108	1	1
10	Brush Holder Insulator	5603-114	4	4
11	Ballrace, Comm. End	RLS5	1	1
12	Lubricator	5244-31B	1	1
13	Oil Guard	53/C2A	1	1
14	Felt Washer	53/D2	1	1
15	Cover Fixing Screw	NS16-10Z1	4	4
16	Brush Holder Pillar	5603-214	4	4
17	Trigger Pillar	5603A-213	4	4
18	Back Plate	5603A-113	4	4
19	Brush Holder	5603A-142A	2	2
20	Brush Trigger	5603A-144	4	4
21	Trigger Spring	5561-16	8	8
22	Insulating Bush	5391-21A	4	4
23	Insulating Washer	5137-5A	8	8
24	Insulating Washer	5339-557	8	8
25	Brush Screw	5335-327	4	4
26	Spring Washer	5293-57	4	4
27	Plain Washer	5083A-1	4	4
28	Nut	5128A-8	8	8
29	Spring Washer	5001-23	8	8
30	Brush	5603-128	4	4
31	Bracket	5603-143A	2	2
32	Term. Box Base, Assembly	5603-45	1	1
	Term. Box Base, Assembly	5603-34	1	1
33	Terminals	5603-37	3	3
34	Terminal Screw	5548A-43	3	3
35	Plain Washer	5068A-2	4	4
36	Insulating Washer	5339-340A	1	1
37	Distance Collar	5339-224	2	2
38	Spring Washer	5293-57	3	3
39	Terminal Nut	5603A-43	3	3
40	Packing Piece	5603A-120	1	1
41	Fixing Screw	5603-39	2	2
42	Terminal Box Lid	5603A-183	1	1
43	Lid Fixing Screw	5337A-50	2	2
44	Nut	5270A-56	3	3
45	Spring Washer	5293-57	3	3
46	Plain Washer	5068A-2	3	3
47	Cable Bush	5603-44A	1	1
48	Cover Clip	5603-101	1	1
49	Cover Clip Packing	5603-100	1	1
50	Cover Band	5603-105	1	1
51	Armature, complete	A.335	1	1
52	Driving End Ballrace	RLS7	1	1

DYNAMO




Dynamo—(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
53	Clamp Plate	5603A-12	1	1
54	Clamp Plate Screw	NS16-27Z1	3	3
55	Spring Washer	5244-22	9	9
56	Driving End Lubricator	5244-31B	1	1
57	Main Fixing Bolt	5603-48	2	2
58	Fixing Bolt Nut	5072A-1	2	2
59	Spring Washer	5293-57	2	2
60	Shaft Collar	5603A-53	1	1
61	Woodruff Key	NK1-8	1	1
62	Spring Washer	5001-49	1	1
63	Shaft Nut	5314-51	1	1
64	Shield Cover	5603A-63	1	1
65	Cover Insulator	5603-262	1	1
66	Driving End Shield	5603C-110	1	1

FOR DYNAMO COMPLETE

(See Page 90)

DYNAMO




Starter

Item No.	Description	Part No.	Cylinders	
			2	3
1	Main Field Coil	F.206	(set) 1	1
2	Main Fixing Bolt	5333-94	4	4
3	Auxiliary and Shunt Coil	F.211	(set) 1	1
4	End Tag	5459-70	4	4
5	Pole Screw	5333-95	4	4
6	Clutch Fixing Key	NK1-19	1	1
7	Armature, wound complete	A.158	1	1
8	Felt Packing Washer	5339-316	1	1
9	Tripping Plate	5586-68	1	1
10	Tripping Plate Screw	5333-102	3	3
11	Split Pin	5549-47	1	1
12	Shaft Locking Nut	5330A-71	1	1
13	Shaft Nut	5330A-70	1	1
14	Washer	5339-139	1	1
15	Felt Washer	5339-281	1	1
16	Shim	5339A-312	1	1
17	Armature Plunger	5586-291	1	1
18	Washer	5339-72A	1	1
19	Spring Washer	5293-57	1	1
20	Nut	5330-99A	1	1
	Commutator End Shield Essembly	5586A-96A	1	1
21	Commutator End Shield	5586A-5	1	1
22	Commutator End Bearing	5586-207	1	1
23	Screw	5333-93	3	3
24	Brush Gear Base	5586-37	1	1
25	Fixing Screw for Base	NS19-12A	3	3
26	Spring Washer	5293-57	3	3
27	Brush Spring	5586-10	4	4
28	Solenoid Switch	BBNFA-11	1	1
29	Spring Washer	5001-31	1	1
30	Nut	5330-114A	1	1
31	Setscrew	NS16-10Z1	5	5
32	Spring Washer	5244-22	9	9
33	Plain Washer	5298A-10	5	5
34	Commutator End Cover	5586-83	1	1
35	Thrust Washer	5586-7	1	1
36	Csk. Headed Screw	NS76-12Y	2	2
37	Neg. Brush Connector	5586-203	1	1
38	Pos. Brush Connector	5586-266	1	1
39	Fixing Screw	NS16-12Z1	4	4
40	Brush, with Tag	5586-12A	4	4
41	Terminal Plate, thick	5586-52	1	1
42	Terminal Plate, thin	5586-51	1	1
43	Nut	5330A-80	2	2
44	Plain Washer	5348-90	1	1
45	Insulating Washer	74-E7	1	1
46	Insulating Bush	5587-1A	1	1
47	Insulating Cover	5551-144	1	1
48	Terminal Screw	5549-206	1	1
49	Solenoid Terminal	5549-198	1	1
50	Pos. Terminal Connector	5586-45	1	1
51	Neg. Terminal Connector	5586-47	1	1
52	Solenoid Connector Screw	NS7-6Z1	1	1
53	Spring Washer	5293-39	1	1

STARTER

J63




Starter-(Cont.)

Item No.	Description	Part No.	Cylinders	
			2	3
54	Insulating Bush	5587-2A	2	2
55	Terminal Locking Plate	5549A-199	2	2
56	Terminal Insulating Plate	5549-190	2	2
57	Terminal Locking Plate	5549A-192	1	1
58	Terminal Distance Piece	5549-191	2	2
59	Spring Washer	5001-26	4	4
60	Terminal Nut	5330-79	4	4
	Clutch Assembly	5586-123A	1	1
61	Clutch Outer Race	5586A-111	1	1
62	Pressure Plate	5549-38	2	2
63	Shim Plate	5549-97/8	As reqd.	
64	Back Ring	5549-36	1	1
65	Clutch Plate	5549-96	4	4
66	Steel Clutch Plate	5549-95	5	5
67	Spring Ring	5586-131	1	1
68	Clutch Plate (large)	5586-115	1	1
69	Clutch Inner Race	5586-113E	1	1
70	Pressure Spring	5549-253B	2	2
71	Pinion Spring	5549-99	1	1
72	Pinion Spring Shim	5339-303	1	1
73	Pinion Sealing Ring	5855-30N	1	1
74	Pinion and Bearing complete	5549-306E	1	1
75	Clutch Supporting Ring	5586-117	1	1
	D.E. Shield and Bearing Assembly	5586-124	1	1
76	Driving End Shield	5586-120	1	1
77	Driving End Bearing	5586-121	1	1
78	Locking Pin	5586-122	1	1
79	Round Cotton Wick	5549-20	1	1
80	Felt Wick	5549-108	1	1
81	Wick Retaining Pad	5586-229	1	1
82	Plug for Spare Lubricator	5586-149	1	1
83	Lubricator	5549-261	1	1
84	Oil Seal	5586-224	1	1
85	Copper Washer	5339-270A	4	4
86	Plain Washer	5339-4	4	4
87	Lubricator Spring	5549-129	1	1
88	Starter Body			

STARTER

J63



LIST OF ENGINE JOINTS—JP2MG/R & JP3MG/R

Description	Part No.	2 Cylinder	3	Material
Combustion Chamber Aux. Joint Ring	10-3-6*	2	3	Copper
Combustion Chamber Main Joint Ring	10-3-91*	2	3	Copper
Crankcase Water Drain Plug Joint	12406	2	2	Fibre
Crankcase Water Flange Joints	10-2-59*	3	4	Fibre
Crankcase Drain Plug Joints	3306	2	2	Fibre
Crankcase Door Joints (Small)	10-2-61A	2	3	Cork
Crankcase Door Joints (Large)	11-2-68	1	—	Fibre
Crankcase Door Joints (Large)	12-2-68	—	1	Fibre
Crankcase Door Joints (Gearside)	12-2-60	1	1	Fibre
Bevel Wheel End Cover Joint	10-2-65	1	1	Paper
Bevel Wheel Housing Joint	10-2-114	1	1	Paper
End Cover Joint	10-2-63	1	1	Paper
Camshaft Bearing Screw Joint	10-2-180	1	1	C & A
Dust Cover Joint	10-2-64A	1	1	Paper
Main Bearing Gear End Joint	10-2-62A	1	1	Paper
Cylinder Head Gasket	10-3-105*	2	3	C & A
Copper Shims	10-3-179*	2	3	Copper
Inlet and Exhaust Flange Joints	10-3-57*	4	6	C & A
Joint Silencer—Manifold	11-13-206*	1	1	C & A
Joint Silencer—Crankcase	11-13-901	1	1	Fibre
Joint Exhaust Flange—Silencer	11-13-422	1	1	C & A
Joint Silencer Water Outlet Elbow	27-2068	1	1	Fibre
Filter Joint for Cover (Single)	23-2278	1	1	Fibre
Filter Drain Plug Joint (Single)	103-91	1	1	Copper
Filter Swivel Union Joints	291-2265	6	6	Copper
Gov. Lever Bracket Joints	10-6-48A	1	1	Paper
Support Flange Joint	10-2-67A	1	1	Paper
Oil Pump Cover Joints	10-2-113	2	2	Paper
Liner Rubber Rings	10-2-116	4	6	Rubber
Pump Joint for Bottom Flange	10-2-115	1	1	Cork
Oil Relief Valve Joints	12406	8	8	Fibre
Manifold Drain Plug Joints	5197	3	3	Fibre
Fuel Injector Joints	10-3-41*	2	3	Copper
Oil Pump Joint to Crankcase	10-2-112	1	1	Paper
Water Pump Joint (Cover to Bracket)	11-13-315	1	1	Paper
Joint—Water Pump Valve Cage	11-13-379	2	2	Fibre
Joint Washer for Connections	12419	4	4	Fibre
Joint for Plugs and Connections	3306	7	7	Fibre
Joint for ¼ Gas Drain Plugs	5197	2	2	Fibre
Filter Cover Joint (Duplex)	10-2-328	2	2	Fibre
Filter Plug Joints (Duplex)	10-2-338	5	5	Fibre
Filter Plug Joint (Duplex)	10-2-339	2	2	Fibre
Filter Plug Joint (Duplex)	103-91	2	2	Fibre
Filter Union Screw Joint (Duplex)	291-2265	4	4	Copper
Joint Rev. Gearcase to Crankcase	614-557	1	1	Paper
Joint Top to Bottom Gearcase	614-558	2	2	Paper
Joint Inspection Cover	23-3453	1	1	Fibre

* Joints for Decarbonising only.

EXTRA FOR REDUCTION GEAR

Description	Part No.	Cylinder		Material
		2	3	
Joint for Red. Gear Water Flange (G/R only) ...	X87/10290	2	2	Fibre
Joint for Red. Gear Water Jacket Cover (G/R only) ...	X99/2214	1	1	Fibre
Joint for Red. Gear (G/R only) ...	X99/2215	1	1	Paper
Joint for Red. Gear (G/R only) ...	X87/11820	1	1	Paper

EXTRA FOR FRESH WATER COOLING

Description	Part No.	Cylinder		Material
		2	3	
Centrifugal Pump				
Housing Joint ...	13-14-166	1	1	Paper
Housing Joint ...	614-434	1	1	Paper
Cover Joint ...	13-14-153	1	1	Paper
Water Pump Cover Joint ...	294-725	1	1	Paper
Water Flange Joint ...	3309	6	6	Fibre

JOINTS FOR JP2MG/R & JP3MG/R

JP2MG—Mar. List 78

JP3MG—Mar. List 79

DECARBONISING

Description	Part No.	Cylinder		Material
		2	3	
Combustion Chamber Aux. Joint Ring ...	10-3-6	2	3	Copper
Combustion Chamber Main Joint Ring ...	10-3-91	2	3	Copper
Crankcase Water Flange Joints ...	10-2-59	3	3	Fibre
Cyl. Head Gasket ...	10-3-105	2	3	C & A
Copper Shims ...	10-3-179	2	3	Copper
Inlet and Exhaust Flange Joints ...	10-3-57	4	6	C & A
Joint Silencer—Manifold ...	11-13-206	1	1	C & A
Fuel Injector Joints ...	10-3-41	2	3	Copper
Joint Washer for Connections ...	12419	4	4	Fibre

LIST OF ENGINE JOINTS—JK2MG/R & JK3MG/R

Description	Part No.	Cylinder		Material
		2	3	
Combustion Chamber Aux. Joint Ring	10-3-6*	2	3	Copper
Combustion Chamber Main Joint Ring	10-3-91*	2	3	Copper
Crankcase Water Drain Plug Joint	12406	2	2	Fibre
Crankcase Water Flange Joints	10-2-59*	3	4	Fibre
Crankcase Drain Plug Joints	3306	2	2	Fibre
Crankcase Door Joints (Small)	10-2-61A	2	3	Cork
Crankcase Door Joints (Large)	11-2-68	1	—	Fibre
Crankcase Door Joints (Large)	12-2-68	—	1	Fibre
Crankcase Door Joints (Gearside)	11-2-60	1	1	Fibre
Bevel Wheel End Cover Joint	10-2-65	1	1	Paper
Bevel Wheel Housing Joint	10-2-114	1	1	Paper
End Cover Joint	10-2-63	1	1	Paper
Camshaft Bearing Screw Joint	10-2-180	1	1	C & A
Dust Cover Joint	10-2-64A	1	1	Paper
Main Bearing Gear End Joint	10-2-62A	1	1	Paper
Cylinder Head Gasket	10-3-105*	2	3	C & A
Copper Shims	10-3-179*	2	3	Copper
Inlet and Exhaust Flange Joints	10-3-57*	4	6	C & A
Joint Silencer—Manifold	11-13-206*	1	1	C & A
Joint Silencer—Crankcase	11-13-901	1	1	Fibre
Joint Exhaust Flange—Silencer	11-13-422	1	1	C & A
Joint Silencer Water Outlet Elbow	27-2068	1	1	Fibre
Filter Joint for Cover (Single)	23-2278	1	1	Fibre
Filter Drain Plug Joint (Single)	103-91	1	1	Copper
Filter Swivel Union Joints	291-2265	6	6	Copper
Gov. Lever Bracket Joints	10-6-48A	1	1	Paper
Support Flange Joint	10-2-67A	1	1	Paper
Oil Pump Cover Joints	10-2-113	2	2	Paper
Liner Rubber Rings	10-2-116	4	6	Rubber
Pump Joint for Bottom Flange	10-2-115	1	1	Cork
Oil Relief Valve Joints	12406	8	8	Fibre
Manifold Drain Plug Joints	5197	3	3	Fibre
Fuel Injector Joints	10-3-41*	2	3	Copper
Oil Pump Joint to Crankcase	10-2-112	1	1	Paper
Joint for Plugs and Connections	600-106	6	8	Fibre
Exhaust Lifting Bracket Joint	10-2-75	2	2	Paper
Joint for ¼ Gas Drain Plugs and Oil Connections	5197	4	4	Fibre
Filter Cover Joint (Duplex)	10-2-328	2	2	Fibre
Filter Plug Joints (Duplex)	10-2-338	5	5	Fibre
Filter Plug Joint (Duplex)	10-2-339	2	2	Fibre
Filter Plug Joint (Duplex)	103-91	2	2	Fibre
Filter Union Screw Joint (Duplex)	291-2265	4	4	Copper
Joint Rev. Gearcase to Crankcase	614-557	1	1	Paper
Joint Ring for Reverse Gear	12-15-483	1	1	Rubber
Joint Top to Bottom Gearcase	614-558	2	2	Paper
Joint Inspection Cover	23-3453	1	1	Fibre
Cylinder Plug Joint	12406	2	3	Fibre
Pipe Connecting Plug Joint	11-3-296	2	3	Fibre
Cylinder Head Lower Joint	11-3-291	2	3	Fibre

* Joints for Decarbonising only.

List of Engine Joints—JK2 & JK3MG/R—(Contd.)

Description	Part No.	Cylinder	
		2	3
Joints for Gear Pump Plate	291-2516/1	6	6
" " Housing	291-2502	2	2
" " Cover	291-2885/1	2	2
" " Bearing Housing	11-15-501	2	2
" " Blank Cover Plate	13-14-153	1	1
" " Plug	600-106	6	8
" " Safety Valve (Pump)	13-21-778	6	6
" " Flange	23-1766	2	2
" " Plug	13-22-350	2	2

EXTRA FOR REDUCTION GEAR

Description	Part No.	Cylinder		Material
		2	3	
Joint for Red. Gear Water Flange (G/R only) ...	X87/10290	2	2	Fibre
Joint for Red. Gear Water Jacket Cover (G/R only) ...	X99/2214	1	1	Fibre
Joint for Red. Gear (G/R only) ...	X99/2215	1	1	Paper
Joint for Red. Gear (G/R only) ...	X87/11820	1	1	Paper

EXTRA FOR FRESH WATER COOLING

Centrifugal Pump				
Housing Joint	13-14-166	1	1	Paper
Cover Joint	13-14-153	1	1	Paper
Water Pump Cover Joint	294-725	1	1	Paper
Water Flange Joint	3309	1	1	Paper
Housing Joints	11-15-501	1	1	Paper

JOINTS FOR JK2MG/R & JK3MG/R

JK2MG—Mar. List 78
JK3MG—Mar. List 79

DECARBONISING

Combustion Chamber Aux. Joint Ring ...	10-3-6	1	1	Copper (Air Starting)
Combustion Chamber Main Joint Ring ...	10-3-91	2	3	Copper
Crankcase Water Flange Joints	10-2-59	3	3	Fibre
Cyl. Head Gasket	10-3-105	2	3	C & A
Copper Shims	10-3-179	2	3	Copper
Inlet and Exhaust Flange Joints	10-3-57	4	6	C & A
Joint Silencer—Manifold	11-13-206	1	1	C & A
Fuel Injector Joints	10-3-41	2	3	Copper
Joint Washer for Connections	12419	4	4	Fibre

Recommended Tools For Dismantling and Assembling C.A.V. Fuel Injection Pump-Types BPE-B and BPF-B

Part No.	Qty.	Description
ET.025 BPE & BPF	... 1	Box Spanner for Delivery Valve Holder
ET.099 BPE & BPF	... 1	Extractor for Delivery Valve Seating
ET.569B, BPE & BPF	... 1	Forceps for Extracting Plunger
ET.428 BPE & BPF	... 1	Forceps for Plunger Guide
ET.148 BPE & BPF	... 1	Calibrating Outfit Complete (including Baseplate ET106)
ET.008 BPE only	... 1	Extractor for Coupling
ET.011 BPE only	... 1	Spanner for Coupling
ET.026A, BUE only	... 1	Extractor for Inner Ball Race
ET.026 BPE only	... 1	Extractor for Outer Ball Race
ET.102 BPE only	... 1	Set of 4 Holders for Tappets
ET.104 BPE only	... 1	Set of 2 Spanners for Adjusting Tappets
ET.105 BPE only	... 1	Spanner for closing Plugs.
ET.122A.	...	C.A.V. Test Pump Outfit
13-22-662	...	Service Type Injector Testing Gauge Assembly
ET.727	...	C.A.V. Injector Cleaning Kit

Note.—Calibrating outfit ET148 is supplied fitted with Baseplate ET106 for use with BPE Type Pumps only.

To convert this outfit for use with BPF Type Pumps it is necessary to use Cam Box ET022 in addition to Baseplate ET106.

SPECIAL TOOLS for SERVICING JPM & JKM-SP.995

Part No.	Description
317-58	S. Liner Extractor and Grinding in Tool, with 27/2327 and 27/2457 Plates
13-23-88	S. Flywheel Extractor—Plate type
27-3866	S. Setscrews for above
27-2	Nuts for above.
10-7-94S	S. Spanner for Flywheel Nut
27-1728	Valve Spring Decompressor
27-750	1 - Set of Taper Reamers comprising :—
27-751	No. 0
27-752	No. 1
27-753	No. 2
27-754	No. 3
27-755	No. 4
27-756	No. 5
13-23-89	No. 6
27-2447	S. Driving Bit for Balance weight Studs.
27-3871	Box Spanner 7/16"
317-53	S. Piston Ring Clips
17226	* Circlip Pliers
25620	S. Valve Seat Cutter
15585	S. Shank
43180	S. Valve Guide Reamer
25620A	S. Holder
X87/11690	S. Tommy Bar
X87/11930	* Spanner for Reverse Gear (Long)
X87/11940	* Tommy Bar for above
	* Spanner for Rev. Gear (Short)

Tools for Gear Pump

* Supplied with Engine.

S. Special Tools.